


# Axe-Fx

## Pre-Amp / Effects Processor



## User's Manual



# Table of Contents

Table of Contents .....	1
Foreword.....	3
Introduction .....	5
What is the Axe-Fx .....	5
Concept .....	8
Getting Set Up .....	10
Rear Panel .....	10
Front Panel.....	11
Example Connections .....	13
I/O Configuration .....	18
Editing.....	23
Placing Effects.....	23
Routing .....	23
Moving Effects.....	24
Editing Effects .....	24
Effect Mixer .....	24
Output Mixer.....	26
Attaching Controllers .....	26
Saving Presets .....	26
Recalling Presets .....	27
The Effects.....	28
Noise Gate .....	28
Compressor.....	28
Filter .....	29
Graphic Equalizer.....	30
Parametric Equalizer .....	31
Chorus.....	32
Flanger .....	33
Phaser.....	35
Rotary Cabinet .....	36
Wah-Wah .....	37
Formant Filter .....	38
Pan / Tremolo.....	39
Delay .....	41
Multi Delay.....	45
Reverb.....	48
Amp Simulator.....	50
Cabinet Simulator.....	58
Drive .....	60
Pitch Shifter.....	61
Stereo Enhancer .....	64
Effects Loop / Aux. Out .....	64

Mixer.....	65
Feedback Send / Return .....	66
Controllers and Modifiers.....	67
Tempo .....	67
LFO's.....	68
ADSR's.....	68
Sequencer .....	69
Envelope .....	69
Pitch .....	70
External Controllers.....	70
Modifiers.....	70
Global Parameters.....	73
Tuner .....	74
Utilities .....	75
LCD .....	75
Preset.....	75
Status .....	76
Reset .....	77
Firmware .....	77
Tips and Tricks .....	78
Achieving ultimate tone .....	78
Using Your Axe-Fx with a Guitar Amp.....	78
Using Your Axe-Fx Live.....	80
Interference .....	80
Maintenance.....	80
Warranty Information .....	81
Specifications.....	82

**WARNING:**

To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

**CAUTION:**

To reduce the risk of fire or electric shock, do not remove screws. No user-serviceable parts inside. Refer servicing to qualified service personnel.

## **IMPORTANT SAFETY INSTRUCTIONS**

1. Obey all warnings on the Axe-Fx and in this User's Guide.
2. Keep away from sources of heat such as heat registers or appliances which produce heat.
3. Connect only to a proper AC outlet of 100 - 240 V, 47 - 63 Hz.
4. Keep power cord in good condition. Do not kink, bend or pinch. If power cord becomes damaged discard and replace.
5. If not using your Axe-Fx for extended periods of time disconnect from AC mains.
6. Protect the unit from rain and excessive moisture.
7. Refer servicing to qualified personnel only.
8. Do not operate the unit and obtain service if:
  - Liquids or excessive moisture enter the unit
  - The unit operates incorrectly or performance is inconsistent or erratic
  - The unit has been dropped and/or the enclosure damaged
9. Prolonged exposure to high volume levels can cause hearing loss and/or damage. Use of hearing protection in high volume situations is recommended.

## **Certificate of Conformity**

Fractal Audio Systems, USA, hereby declares on own responsibility that the following product

### ***Axe-Fx - Digital Guitar Preamp / Effects Processor***

That is covered by this certificate and marked with CE label conforms with following standards:

EN60065 (IEC 60065)	Safety requirement for mains operated electronic and related apparatus for household and similar use.
EN 55103-1	Product family standard for audio, video, audio-visual and entertainment lighting control apparatus for professional use. Part 1: Emission.
EN 55103-2	Product family standard for audio, video, audio-visual and entertainment lighting control apparatus for professional use. Part 2: Immunity.

With reference to regulations in following directives: 73/23/EEC, 89/336/EEC

***Issued in February 2007***

***Clifford Chase  
President***

## **EMC / EMI**

This equipment has been tested and found to comply with the limits for a Class B Digital device, pursuant to part 15 of the FCC rules.

These limits are designed to provide reasonable protection against harmful interference in residential installations. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

# Foreword

Shortly after the advent of the electric guitar and the amplifier, guitar players began to experiment with altering the basic sound of their instruments. Amplifiers soon began to incorporate spring reverb units and then tremolos and overdrive circuitry. Never satisfied, guitarists yearned for even more sonic possibilities and the effect pedal was born. These early pedals were based on discrete semiconductors and consisted of wah-wah, distortion and other simple effects. Although crude, folklore has exalted these early pedals to the point where some feel they were endowed with almost mystical properties due to their germanium transistors or the particular manufacturer of inductors.

With the introduction of the integrated circuit (IC) in the late 1960's designers could now realize more complicated effects. Notable among these were the operational amplifier and later on the bucket-brigade delay line, the latter allowing compact time-based effects to become a reality. By the 1970's a myriad of effect pedals were available to the musician from many different manufacturers. Chorus, phaser and flanger effects became ubiquitous and pervaded the recordings of the time. Many of these pedals were noisy and lacked fidelity, the analog delay lines contributing to significant signal degradation.

As technology marched on and IC's became ever denser, a new paradigm was thrust into the spotlight: digital. Digital effects, it was promised, would offer far superior performance: zero noise, nearly infinite delay times, pristine reverbs, etc. Soon the multi-effect was born. In a single rack-mounted unit the guitarist could have the equivalent of a dozen different effect pedals. Competition was fierce with each manufacturer trying to one-up the other by cramming more and more into their boxes. Ultimately, and unfortunately, this has led to digital's demise.

As engineering gave way to marketing, many soon began to question the Emperor's new clothes. Pricing pressures and cost cutting forced engineers to use low-grade components and inferior algorithms, and the quality of the effects suffered. Grainy, cheesy, noisy. No doubt many have heard these terms when referring to digital effects. Soon, many guitarists rebelled against digital effects and analog pedals have now enjoyed a renaissance. Old analog pedals are prized and sought among vintage collectors. Musicians have ditched their rack processors in favor of a board full of individual effect pedals.

But this is a pity. For digital does not have to carry the stigma that it does. Digital is, in fact, quite capable of delivering the benefits that were originally touted. And now, more than ever, can this be realized, as modern Digital Signal Processors (DSP's) are not only incredibly powerful but relatively inexpensive. The quality of digital audio is hard to refute. Just witness CD and DVD players, MP3 devices and computer audio in general all of which use digital processing. Furthermore, digital offers the convenience of multiple simultaneous effects, programmability and superior control.

With the Fractal Audio Systems Axe-Fx™ we have hopefully restored digital to its rightful place as the superior solution to musical effects processing. Every aspect of the Axe-Fx has been designed to deliver the ultimate in sonic quality. The converters are of the highest quality offering low-noise, high linearity and uncolored performance. The DSP has more raw compute power than many desktop computers allowing uncompromised processing algorithms. All processing is done at 32-bit precision yielding uncolored, transparent sound.

We hope you enjoy using the Axe-Fx as much as we enjoyed designing it. Over three years of development have gone into making what we hope is the quintessential effects processor.

**NOTE:**

Fractal Audio Systems, Axe-Fx and Dynamic Response Technology are trademarks of Fractal Audio Systems. All other product names, trademarks, and artists' names are the property of their respective owners, which are in no way associated or affiliated with Fractal Audio Systems.

# Introduction

Thank you for purchasing an Axe-Fx Pre-Amp / Effects Processor. You're now the owner of one of the most powerful instrument processors ever produced. By familiarizing yourself with this manual you'll be able to reap the full benefits of your unit. Please take a moment to read through the sections that follow and acquaint yourself with the usage of your Axe-Fx.

## What is the Axe-Fx

What is the Axe-Fx? Well, let's start by telling you what it isn't.

It's not a modeler in the strict sense. Although it has cabinet emulation and different amplifier "types" it does not attempt to model any amplifier or effect exactly. Rather the Axe-Fx was designed to simply provide the effect as originally intended and with the utmost quality. All effects can be described in terms of their desired sonic manipulation. All effect processors, whether "stomp boxes" or otherwise, process the input signal to get an output signal, simple as that. However, some processors obviously do better than others. The Axe-Fx approaches effects processing as a strict set of specifications and implements those specifications.

For example, the wah effect in the Axe-Fx is not intended to model any of the classic wah-wahs. Instead the input-output relationship of a wah was distilled into a set of specifications. From there the effect was designed to exactly meet these specifications. There is no "black magic" or obfuscation. The effect does exactly what it should do. Inherent in this approach is a degree of flexibility that you do not get with other processors. In our wah example this allows you to set the sweep range, "Q" and other parameters. Most modeling processors do not allow this level of control.

The Axe-Fx's amp, drive and cabinet simulations, however, are very faithful reproductions of the originals, but without the drawbacks of the originals. What this means is that they sound like the originals but are easier to adjust and provide more flexibility and a wider range of tones. For example, the Brownface amp sim sounds remarkably like a particular classic amp however the Axe-Fx contains working midrange and presence controls. Also the tone controls are much more responsive providing all the tones of the original plus new tones that the original could not achieve. Once again the philosophy is practicality and presenting the "effect" as it was originally intended.

The Axe-Fx does not use any analog processing or any tubes. If you look inside<sup>1</sup> the Axe-Fx you will not see any glowing tubes or any of the revered op-amps that the analog pundits claim offer mystical sonic properties. What you will see are modern, high-quality components that offer specifications and performance far exceeding any of the aforementioned devices.

---

1. Please do not open your Axe-Fx as damage may occur. Refer all servicing to qualified personnel.



The Axe-Fx does contain, however, very accurate digital replicas of actual vacuum tubes. We gathered up some classic tubes and measured their transfer functions and then stored these transfer functions in the Axe-Fx's massive brain. Our replicas are so exact that we can reproduce the harmonic spectrum of a real tube amp with amazing accuracy. Most modelers don't even come close.

OK, so what does it do? Well, the Axe-Fx is fully routable, fully programmable, real-time controllable, multi-effects processor. Whew, that's a mouthful. Let's examine each of these attributes:

**Routability:** The Axe-Fx allows you to place effects in any order and in series or parallel. Also, the effects loop is routable as well so if you use your Axe-Fx with a preamplifier you can place the preamplifier in the effects loop and run effects both before and after your preamp. Some effects work better when placed before distortion (which your preamp would provide) and others work better after. By providing a routable effects loop the Axe-Fx allows unrivaled flexibility.

**Programmability:** The Axe-Fx allows extensive programmability of each effects parameters. You are not constrained by the limitations of "one-knob" processors where little if any editing of parameters is offered. In addition, many effects offer advanced editing capability allowing in-depth programming. Usability has not been sacrificed though as most effects have a basic setup page allowing quick access to the most used parameters.

**Controllability:** Many of the parameters in the Axe-Fx are controllable in real-time. Both internal and external controllers can be attached to various parameters offering dynamic control of an effect. Additionally these controllers allow mapping the control value to the effect parameter through a transform so even greater control is afforded.

**Multiple Effects:** The Axe-Fx has all the classic effects plus a few new ones. And for most effects you get two instances so you can really create some huge sounds. The Axe-Fx works on the principle of an "effects inventory". You take an effect out of inventory and place it in the routing grid and then connect it to other effects and connect controllers to it (if desired). If an effect has multiple instances you can withdraw another instance of that same effect from the inventory and place it at another location in the grid. The effects inventory is listed below along with the number of instances available:

- Noise Gate (1)
- Compressor (2)
- Graphic Equalizer (2)
- Parametric Equalizer (2)
- Amplifier Emulator (2)
- Cabinet Emulator (2)
- Reverb (2)
- Chorus (2)

- Flanger (2)
- Phaser (2)
- Rotary Cabinet (2)
- Wah-Wah (2)
- Formant Synthesizer (1)
- Tremolo/Panner (2)
- Delay (2)
- Multi-Delay (2)
- Filter (2)
- Pitch Shifter (1)
- Drive (2)
- Stereo Enhancer (1)
- Mixer (2)
- Effects Loop (1)
- Feedback Send/Return (1)

Despite the huge arsenal of effects at your disposal, the Axe-Fx first-and-foremost emphasizes sound quality. Unique to the processing in the Axe-Fx is our proprietary natural processing algorithms. Many of the algorithms in the Axe-Fx replicate patterns that occur in nature (this is where our company name was derived from). The reverb algorithm replicates the sound of a real room, the chorus and flanger use special variable delay algorithms that are more natural and smooth than any pedal (analog or digital) could ever achieve and the amp simulations use unique, dynamic, non-linearity generators that produce smooth, even-ordered harmonics giving a depth to the sound that other processors lack. Almost all the effects in the Axe-Fx are full stereo (except for the Amp, Drive, Pitch and Multi-Delay effects) allowing for rich, full-sounding signal chains. And by using two Amp blocks you can achieve a true stereo, dual-amp rig for really huge sounds.

Along with our superior algorithms the Axe-Fx uses the finest quality components available. The op-amps, A/D and D/A converters and passive components are all of the highest quality. The converters are the same converters used in high-end studio equipment costing many thousands of dollars. A single op-amp in the Axe-Fx costs more than all the op-amps combined in many “budget” processors. Additionally our unique analog topology eliminates any electrolytic capacitors from the signal path. Only high-quality film capacitors and precision metal-film resistors are used in the signal path assuring low-noise and low-distortion performance. These features also allow the Axe-Fx to excel as a general purpose outboard processor for studio and live use.

## Concept

The Axe-Fx works on the concept of an effects inventory and an effects grid.




Figure 1. Axe-Fx Concept

The effects inventory is a virtual stockroom of effects. Effects are removed from the inventory and placed into the effects grid. The grid is a four row by twelve column matrix. Once an effect has been placed in the grid it can be connected to any other effect in an adjacent column. Routing beyond the adjacent columns is not permitted. Figure 1 shows the conceptual model along with a somewhat simple routing. The input feeds the “WAH” block which feeds an “AMP” block which in turn feeds the “CAB” block, etc. A second series path has another amp and cab and this path is added to the first path at the input to the chorus (CHO). Signal flow is always left-to-right. We’ll cover routing in more detail later.

Every effect has a common input-output structure. The input sums the outputs of the effects that feed into the effect. Each effect can have up to four inputs from the previous column. In turn each effect can feed its output to up to four effects in the subsequent column.




Figure 2. Effect Block I/O Structure

The Output Mixer (the block labeled “OUTPUT” in Figure 1) sums the signals from the four rows. The Output Mixer allows mixing and panning of the four rows and overall level control.




Figure 3. Output Mixer

# Getting Set Up

## Rear Panel

Figure 4. shows the rear panel of the Axe-Fx.




Figure 4. Rear Panel

1. **Input1** - Connect line-level input sources to these jacks. If using the Axe-Fx as an effects processor use these jacks and be sure to set the **INPUT SOURCE** to **ANALOG REAR** in the **I/O** menu.  
*NOTE: The front panel INSTR input is defeated whenever a plug is inserted into this input.*
2. **Input2 / Eff. Return** - If using the effects loop the output of the effect(s) in the loop are connected here. You can also use this as a generic input by placing the effects loop block in the grid but not connecting anything to the block's input.
3. **Output1** - Main outputs. There are two sets of outputs, unbalanced and balanced. The balanced outputs are intended for use with a mixing board and balanced cables (mic cables). The unbalanced outputs are intended for connecting to a power amp or other unbalanced equipment. The **GND LIFT** switch lifts the shield ground on the balanced outputs. If you get hum using the balanced outputs flip this switch to isolate the ground.
4. **Output2 / Eff. Send** - Connect this to the input of the effect(s) in your effects loop. You can also use this as an auxiliary output for on-stage monitoring or other uses.
5. **Digital I/O** - The **IN** connector provides 24-bit / 48 kHz digital input to the Axe-Fx. When configured to use the digital input, **INPUT1** is defeated and the effects loop is not active (see *I/O Configuration*). The **OUT** connectors provide a digital version of the audio from **OUTPUT1**. The format is 24-bit / 48 kHz.

Digital audio output is provided on both RCA and XLR connectors. Digital in is provided on an RCA connector. You can connect an AES digital source (XLR connector) to the RCA digital input jack using commonly available AES to SPDIF adaptor cables.

6. **MIDI** - MIDI interface. Connect your MIDI controller to MIDI IN. The **POWER** jack provides power on pins 6 and 7 of MIDI IN allowing phantom powering of pedal boards that support this.
  7. **Pedal / Footswitch** - Pedal / footswitch inputs. Connect your expression pedals and/or footswitches here. Each jack is a ¼" stereo jack capable of supporting an expression pedal or a footswitch (either momentary or latching).
- When connecting an expression pedal the pedal data can be used to control various parameters continuously such as volume, rate, drive, etc. A footswitch would normally be used to control bypass or preset recall. See the *I/O Configuration* section for more information on pedal types and configuration.
8. **A/C In** - Mains power. Connect to a grounded AC receptacle.

## Front Panel

Figure 5 shows the front panel of the Axe-Fx.




Figure 5. Front Panel

1. **Status / Warning Indicators** - These four LED's consist of:

**EDITED** - Lit if the current preset has been edited, reminding you to save your changes.

**MIDI IN** - Lights whenever MIDI data is received.

**OUT1 CLIP** - Lights whenever the digital signal level at **OUTPUT1** has exceeded that which is representable by 24-bits. Internally the Axe-Fx uses 32-bit floating-point numbers so clipping is virtually impossible. These values are then converted to 24-bit fixed-point numbers prior to being output. If the converted value is greater than that which can be represented by a 24-bit fixed-point number, this will cause clipping of the D/A converter and clipping of the digital output. If the clipping is severe audible distortion may result. Reduce the output level by either turning down the level in one or more of the effect blocks or by turning the master output level down in the layout mixer.

**OUT2 CLIP** - Lights whenever the signal level at **OUTPUT2** has exceeded that which is representable by 24-bits. Reduce the output level by either turning down the level in one or more of the effect blocks or by turning the master output level down in the effects loop mixer.

2. **Value / Enter / Exit** - The value dial is used to adjust values of various parameters. The **ENTER** button is used to commit effects to a block, attach controllers and various other activities. The **EXIT** button cancels dialogs and escapes from various states
3. **Navigation** - The four navigation buttons allow movement within a page. The **PAGE** buttons switch between pages.
4. **Menu** Pressing a menu button brings you to that menu instantly:

**LAYOUT** - This is the effects grid placement and routing menu. There are four pages: **EDIT**, **MOVE**, **GATE** and **MIX**. The **EDIT** page is used to place and route effects. The **MOVE** page allows moving an effect once it's been placed. The **GATE** page contains the adjustable parameters for the Noise Gate. The **MIX** page allows overall mixing and panning of the four rows in the grid as well as overall output level adjustment.

**EDIT** - To edit an individual effect, highlight that effect in the **LAYOUT>EDIT** menu and press **EDIT**. This brings up the edit pages for that effect. Pressing **EDIT** again switches to the next effect in the grid.

**CONTROL** - Pressing **CONTROL** brings up the menu pages for the internal controllers. These are **TEMPO**, **LFO1**, **LFO2**, **ADSR1**, **ADSR2**, **ENV** and **MODS**. These are discussed in more detail in the controllers section.

**EFF. BYP** - To bypass an individual effect, highlight the effect and press **EFF. BYP**. The outline of the effect in the grid will change to a dotted line indicating the effect has been bypassed. Pressing the button again will restore the effect.

**GLOBAL** - This brings up the Global parameters menu. There are three pages: **OUT1**, **OUT2**, and **MIX**. These are discussed in more detail in the Global section.

**TUNER** - Pressing this button brings up the tuner display.

**I/O** - This button brings up the I/O Setup menu. This menu allows you to configure the various audio and control options of the Axe-Fx. See the I/O Section for more details.

**UTILITY** - This menu contains various utility functions. See the Utility section for more details.

**RECALL** - Brings up the Recall display and allows you to recall presets using the value dial.

**STORE** - Enters the Store menu allowing naming and saving of the current preset.

**BYPASS** - Pressing this button bypasses the Axe-Fx. The LED on the button is lit indicating the bypass state. Press the button again to defeat the bypass. Pressing this button twice in rapid succession restores all parameters of the selected effect to their default values.

**TEMPO** - Tap the song tempo using this button. The LED on the button flashes at the tempo that was tapped in. The tempo is saved with the preset but may be overridden at any time. Recalling a preset loads the tempo of that preset. Any effects set to use tempo will adjust their dependent parameters to the current tempo.

## 5. Level Controls

**INPUT 1/2** - These controls set the input levels to the A/D converters. For best signal-to-noise ratio adjust the levels until the top red LED just barely lights on the strongest peaks. For example, adjust **INPUT 1** so that when you strum your guitar loudly with its volume all the way up the red LED should light only occasionally. Setting the level controls too high may result in clipping of the input causing audible distortion. For guitars with humbucking pickups the **INPUT 1** control will normally be around the 2:00 position. For single coils you may wish to set this control slightly higher.

For best results when plugging line-level devices into an input set the controls at midpoint and adjust the output level of the device so that the red LED barely lights on the strongest signal peaks.

The LED's indicate the signal level at the A/D converter. When the red LED lights the signal into the A/D is 6 dB below full-scale (6 dB headroom).

**OUTPUT 1/2** - These controls set the output level of the Axe-Fx. Adjust these to suit the equipment connected to the outputs. Setting the levels too high may result in clipping of the attached equipment. The Axe-Fx is capable of delivering about +18 dBu maximum with level controls at full.

6. **Instr** - Plug your guitar into this jack. This input is conditioned especially for use with your guitar. Plugging a line-level device into this input is not recommended as this may cause clipping of the input amplifier. Be sure to set the **INPUT SOURCE** to **ANALOG FRONT** in the **I/O** menu. If a plug is inserted into the **INPUT 1 LEFT/MONO** jack on the rear panel this input is defeated.

## Example Connections

Below are examples of the Axe-Fx in various configurations along with explanations and tips on usage.




## As an Effects Unit with Separate Preamp and Power Amp

The Axe-Fx can be used as an effects processor along with a dedicated preamp and power amp. In this configuration the preamp provides the primary distortion and tone shaping while the Axe-Fx provides effects. By using the preamp in the Axe-Fx's effects loop you can place effects both before and after the preamp. Certain effects, like wah and phaser, tend to work better before distortion, whereas time-based effects such as delay, chorus, reverb, etc. sound best after distortion.


This configuration also allows you to use the Axe-Fx amp simulations as well. In this way you can use the outboard preamp for certain sounds, and the Axe-Fx for others. Be warned, however, after using the Axe-Fx's amp sims you may find your preamp redundant and just adding unnecessary weight to your rack!

Of course you can always use the Axe-Fx between the preamp and power amp, if desired, in the classic post-distortion configuration.




## As an Effects Unit with a Combo Amp (or Head and Cab)

Below are two possible configurations for using the Axe-Fx with a combo amp (or head and cabinet). In the first configuration the Axe-Fx is simply used in the effects loop of the amp. The second configuration is more complicated but allows effects both before and after the amp's preamp stage. In this configuration you are using the amp in the Axe-Fx's effects loop.



## As a Preamp / Processor Into a Power Amp and Guitar Cabinet(s)

In this configuration the Axe-Fx is providing all distortion and tone-shaping. The output of the Axe-Fx is connected to a power amp and cabinets equipped with guitar speakers. Since the cabinets are not full-range, the cabinet simulation in the Axe-Fx should be defeated. This can be done globally via the **GLOBAL** menu, or per-preset by bypassing the cabinet block or removing it from the signal chain. If the power amp is a tube amp you may want to bypass the Axe-Fx power amp simulations as well. This can be done via the **GLOBAL** menu, or per-preset by turning the **SAG** control fully counter-clockwise.




### **As a Preamp / Processor Into a Full-Range System**

In this configuration the Axe-Fx is providing all distortion and tone-shaping. The output of the Axe-Fx is connected to a full-range sound reinforcement system. Since the system is full-range the Axe-Fx's cabinet simulation should be active.

The configuration shown would be typical of using the Axe-Fx straight into a FOH mixer. Your sound man would then send you your sound back into your stage monitor(s).

You can also use this configuration without the mixer as a stage rig. Simply connect the Axe-Fx into a power amp and full-range speakers for the ultimate in tonal flexibility.



## Recording

Using the Axe-Fx in the studio is straightforward. Simply connect the main outputs (analog or digital) to a mixer, computer, etc.

## I/O Configuration

Press the **I/O** button to access the **I/O** configuration menus. These menus allow you to configure the audio, MIDI and pedals of the Axe-Fx.

### Mode Configuration

The first page of the **I/O** menu configures the primary input source. Setting the **INPUT SOURCE** to **ANALOG FRONT** or **ANALOG REAR** configures the unit to slave all clocks to the internal 48 kHz word clock. Setting to **DIGITAL** selects the **DIGITAL** input as the main input and slaves all clocks to this bit stream.

The Axe-Fx can only run at 48 kHz. If you connect a digital source to the unit be sure that its sample rate is 48 kHz.

Set the **INPUT SOURCE** to **ANALOG FRONT** when using the front-panel input. This input is conditioned to provide optimum noise performance for use with an electric guitar.

Set the **INPUT SOURCE** to **ANALOG REAR** when using the rear-panel input. This input is a generic line-level input and works with any line-level source.

### Audio Configuration

The next page of the **I/O** menu configures the inputs to the Axe-Fx. Select the desired mode for each of the inputs as follows:

**LEFT ONLY** - Use for monophonic input sources. For **INPUT 1** use the front panel **INSTR** jack or the rear panel **INPUT1 - LEFT / MONO** jack (set **INPUT SOURCE** as described above). For **INPUT 2** use the rear panel **INPUT2 - LEFT / MONO** jack. In this mode the left input signal is copied to the right channel.

**L+R SUM** - Use when you wish to sum two sources using the **LEFT** and **RIGHT** input jacks.

**STEREO** - Select this if your input source is stereo.

### MIDI Configuration

The **MIDI** page configures the MIDI parameters and preset mapping of the Axe-Fx. The Axe-Fx contains memory for 384 presets. From a MIDI standpoint these presets are arranged in 3 banks of 128 each. To recall presets above 127 your MIDI device must be capable of transmitting a MIDI Bank Select Coarse controller message (controller #0). The value of this message selects the bank (0 - 2). Subsequent MIDI Program Change messages access programs from the selected bank.

**MIDI CHANNEL** - Selects the MIDI channel to which the Axe-Fx will respond. If set to **OMNI** the Axe-Fx will respond to MIDI messages on all channels.

**PROG CHANGE** - When set to **ON** the Axe-Fx will respond to MIDI Program Change messages. When set to **OFF** it will ignore them.

**MAPPING MODE** - When set to **OFF** the Axe-Fx will recall the preset given in the Program Change message. When set to **CUSTOM** you can set up a custom map where an incoming number is mapped to a desired preset

**MAP FROM** - Sets the input MIDI Program Change number that is mapped.

**MAP TO** - The actual preset that is recalled when the **MAP FROM** number is received.

*NOTE: Mapping is only supported within Bank A (presets 0 - 127).*

**SYSEX ID** - Sets the System Exclusive ID of the unit.

## Control Configuration

The **CTRL** page configures the external control capabilities of the Axe-Fx. Each item in the list can be controlled by either of the pedals or by a MIDI continuous controller. To set up the control for an item simply turn the value dial to select the MIDI continuous controller number (or desired pedal) that will control that item. The Axe-Fx has a “learn” feature that allows it to detect the controller. Simply select the desired item to control and press **ENTER**. Now move the controller and the Axe-Fx will learn the controller number.

### *Example*

To set the main output volume to be controlled by Pedal1 select **OUT1 VOLUME** with the navigation buttons. Then turn the value dial to select **PEDAL1**. Alternatively press **ENTER** and then move your pedal connected to the **PEDAL1** jack until the Axe-Fx learns the source.

In the list there are eight external controllers labeled **EXTERNAL 1**, **EXTERNAL 2**, etc. These are the external sources that can be attached to controllable parameters. The actual source can be either of the **PEDAL** inputs or any MIDI continuous controller.

### *Example*

Manual control of effects like Wah requires an external controller to be attached to the Wah's **CTRL** knob. In this example we'll assume an expression pedal is connected to the **PEDAL 2** input jack. The first step is to assign **PEDAL 2** to an external controller. In this case we'll use **EXTERNAL 1**. To do this select **EXTERNAL 1** with the navigation buttons and turn the value dial until **PEDAL 2** is displayed (or use the Auto-Learn function). Now when you attach a modifier to the Wah's **CTRL** knob simply select **EXTRN 1** as the control source.

In this example we could have used any of the eight external controllers or any MIDI continuous controller. The main point to understand here is that there are eight logical external control sources. Each source is assigned to a physical source via the **CTRL** menu page. This source can be the **PEDAL** inputs or a MIDI continuous controller. The logical source is then attached to an effects parameter (via the **MODIFIER** menu, see the *Controllers and Modifiers* chapter).

**GLOBAL BYPASS** - The Global Bypass controller is a special type of bypass control. Whenever the Axe-Fx receives a Global Bypass controller message it toggles the state of any effects that were bypassed in the current preset. For example, if a preset has a Wah in it and that preset is saved with the Wah in a bypassed state the Global Bypass message would un-bypass it. This controller can be used as a universal master bypass control that toggles the bypassed blocks for each preset. Normally you would have to remember what effect is bypassed in a preset and then send the appropriate controller for that effect. With the Global Bypass, however, you can use a single controller to toggle effects for each preset on and off. For some presets you may have a Drive block that you wish to toggle on/off to switch between rhythm and lead work. For others you may have a Wah or Flanger or whatever that you wish to toggle. So instead of having to use a different controller for each preset you can simplify and just use one.

When a preset is recalled the effects are in the bypass state that they were stored in. Any that are bypassed may then be activated using either their individual bypass controllers or all may be activated by using the Global Bypass.

**EFFECT BYPASS** - Each effect in the Axe-Fx can be toggled in and out of bypass using a MIDI continuous controller. Following the Global Bypass item are the individual bypass controllers. Simply set the value to the desired controller number (or pedal number).

### *Example*

To control the bypass state of Flanger 1 use the navigation buttons to select FLANGER 1 BYP. Then turn the value knob (or press ENTER to automatically learn) to select the desired controller number. In this example we'll use CC# 12. Now whenever the Axe-Fx receives a CC# 12 message the bypass state of Flanger 1 will be set to the value of the controller.

Note that the Axe-Fx uses negative logic for the bypass state. A controller value of zero bypasses the effect and non-zero the effect is active. So if the controller value equals zero, effect off, controller value greater than zero, effect on.

## **Pedal Configuration**

The **PEDAL** page configures the pedals. The pedals can be used for parameter control, volume control, effect bypass, preset switching and other purposes. When used for preset switching the Axe-Fx can change presets without the use of a MIDI controller.

The two pedal jacks on the back of the Axe-Fx support continuous, momentary or latching pedals. Continuous pedals are normally used for real-time continuous control of effect or global parameters (i.e. volume). The other types are normally used for bypass control or preset switching. It is important to understand how the various pedal modes operate to use them to the ultimate capability.

To use the pedal for switching operations such as bypass or preset change be sure to set the pedal type to match the type of footswitch. Momentary footswitches close a contact while the pedal is depressed. They typically do not "click" when pressed. Latching footswitches alternate between contacts closed and opened each time the switch is depressed, they usually click.

Internally the Axe-Fx stores a state for the pedal. For momentary footswitches depressing the switch toggles the internal state between 0 and 1. When set to latching the state of the contacts sets the internal state: contacts closed = 0, contacts open = 1.

Footswitches are normally used to control an effects bypass state or for preset increment/decrement. Of course one can still assign a footswitch as an external controller but the "value" from the switch will be either 0 or 1. This may be used, for example, to change the rate of a Rotary simulator between two speeds, when the controller is at value 0 the rate would be slow and when at 1 the rate would be fast. This would be setup using a modifier on the Rotary simulator rate control.

When using a footswitch to control preset recall, a change of state causes a preset change. For example, if a momentary footswitch is connected depressing the switch toggles the internal state. This in turn would increment/decrement the current preset if configured as such. However, if a latching footswitch were connected but the type is incorrectly set to momentary then the preset would only change every other time the pedal was depressed as it would interpret the first press as the pedal being depressed and the second press as the pedal being released.

If the pedal type is set to continuous it CANNOT be used to control bypass or preset change. This prevents unwanted behavior in the event the I/O setup is not exact.

## **Pedal Setup Parameters**

**PEDAL1 TYPE** - Chooses the type of pedal: continuous, momentary or latching.

**PEDAL2 TYPE** - Chooses the type of pedal: continuous, momentary or latching.

**PRESET INCR** - Chooses which pedal to use to increment the preset. When the selected pedal is depressed the next preset will be recalled.

**PRESET DECR** - Chooses which pedal to use to decrement the preset.

**PRESET START/END** - When using a footswitch to control preset increment/decrement the preset recalled will range between these values, wrapping around at the limits. For example if you wish to use a single footswitch to change presets you could plug it into **PEDAL 2** and set **PRESET INCR** to **PEDAL2**. Each time you press the footswitch the preset will increment by one until the **PRESET END** value is exceed in which case it will jump to the **PRESET START** value. If you wish to cycle through presets 10 through 14 you would set **PRESET START** to **10** and **PRESET END** to **14**.



**PEDAL1 CAL** - To calibrate a continuous pedal connected to **PEDAL 1** press **ENTER** and move the pedal through its full range several times. Press **ENTER** again when finished.

**PEDAL2 CAL** - To calibrate a continuous pedal connected to **PEDAL 2** press **ENTER** and move the pedal through its full range several times. Press **ENTER** again when finished.

# Editing

Eventually you'll probably want to build your own presets. With the Axe-Fx this is easy and straightforward. There are three basic steps: placement, routing and effect editing.

## Placing Effects

Press the **LAYOUT** button. Use the **PAGE** buttons to get to the **EDIT** page. This page shows you a portion of the routing grid. The complete grid is 4 rows by 12 columns. Effects can be placed at any position in the grid. Move the cursor using the navigation buttons until the desired block is highlighted.

To change the effect at this grid position use the value dial. As you turn the dial the effect type is displayed in an overlay box. When you reach the desired effect press **ENTER** to place the effect. For this example let's place a compressor. Turn the value dial until **COMPRESSOR 1** is displayed. Then press **ENTER** to place the effect. The block should now display **CMP** indicating that a compressor is in this position.

You may be asking what those blocks with the lines through them are. These are called shunts and allow routing through grid positions. Additionally, shunts sum up to four inputs allowing hybrid serial/parallel routings. When no effect (or shunt) is present the grid block is represented by a dotted outline with an empty interior.

Let's place another effect in the block to the right of the compressor. Move to that position using the navigation buttons and then using the dial wheel select **CHORUS 1**. Press **ENTER** to place the effect.

## Routing

The lines between blocks are routing indicators. Any effect in a column can be connected to any other effect in the adjacent columns. To create or delete a route, highlight the source effect using the navigation buttons and then press **ENTER**. The adjacent block in the next column will blink. Move the blinking cursor to the desired destination block and press enter. If no route was present a route will be added. If a route was present then it will be deleted. Movement is only allowed vertically in routing mode. To cancel routing press **EXIT**. Note that effects in the first column are automatically connected to the input and effects in the last column are automatically connected to the output. An effect can have multiple inputs and outputs. Inputs are summed prior to processing. An empty block can not be routed from/to. Removing an effect and replacing it with an empty block will delete all routes to that block.

## Auto Routing

Instead of having to manually set empty blocks to shunts to complete an effects chain the Axe-Fx contains an auto routing feature. By pressing and holding **ENTER** the Axe-Fx will automatically change an empty block to a shunt and place a route. Simply hold **ENTER** down until the chain completes routing to the output.

## Moving Effects

Effects can be moved once placed. To do this select the **MOVE** page using the **PAGE** buttons. Highlight the desired block (or row or column) to be moved and then select the appropriate move function using the value dial. Press **ENTER** to execute the function. When moving a block in a complex routing the routing to that block may be destroyed. In this case you will need to restore the routing. Simply use the **ENTER** button as usual to reroute the block.

## Editing Effects

To edit the effect press the **EDIT** button. This brings up the edit display for that effect. If more than one effect is present in a preset successive presses of the **EDIT** button will bring up the next effect's edit display. Try it.

Bring up the Chorus edit display. There are three pages in this display. The first page is the **BASIC** page. Most effects have a basic editing page allowing quick access to the most frequently used parameters. Use the navigation buttons to move around in the page. Change the parameter values using the value dial. To access the other pages in the display use the **PAGE** buttons. The chorus also has an **ADV** (advanced) page. This offers in-depth editing of all the parameters available in the chorus effect.

*NOTE: To reset an effect to its default parameters double-click the **BYPASS** button.*

## Effect Mixer

Each effect has an output mixer. Its controls are usually on the **MIX** page. Use the **PAGE** buttons to access the **MIX** page. Most effects have a **MIX** page like this. The **MIX** page allows you to control the mix, level, panning and bypass mode of the effect. On some effects these controls may be duplicated on other pages as they are frequently used. Not all effects have a **MIX** or **GLBL MIX** control. These are effects that don't mix wet and dry but just output processed (100% wet) signals. Examples are the equalizers and the Amp Simulator.

The **MIX** control controls the ratio of wet and dry signals. With the control fully clockwise the output signal of the effect is 100% wet meaning that only the effected signal is present. For effects like chorus, reverb, delay etc. adjust the **MIX** control to achieve the desired effect amount. When routing effects in parallel you'll often want to set the mix to 100% and use the **LEVEL** control to control the mix of that effect.

The **LEVEL** control controls the output level of the block. The mixed signal is increased or decreased according to this control. The proper way to set the level is to bypass the effect using the **EFF BYP** button and compare the levels. Adjust the level until the volume is the same with the effect active. You may desire some boost with a particular effect active (distortion for example) so you can also increase the level to achieve this.

The **PAN** control controls the output panning of the mixed signal. Every effect in the Axe-Fx has stereo outputs. With the control at 12:00 the signal is equal in both the left and right channels. Turning the control left or right pans the signal accordingly. The **PAN** control can be used to achieve complex stereo routings with different effects on the left and right.

The **BYPASS** mode controls the operation of the effect when the block is bypassed. There are three modes of operation for most effects:

- **MIX = 0%** : In this mode the **MIX** control is effectively turned to 0 and the **LEVEL** control to 0 dB. The block is effectively the same as a shunt in this case.
- **MUTE FX OUT** : In this mode the wet signal is muted and the dry signal is preserved at the level set by the **MIX** and **LEVEL** controls.
- **MUTE OUT** : In this mode the output of the block is shut off (both wet and dry muted).
- **MUTE FX IN** : In this mode the effects input of the block is muted and the dry signal is preserved at the level set by the **MIX** and **LEVEL** controls. Only the Reverb, Delay and Pitch blocks have this mode. This allows the effect to continue after the effect has been bypassed. This mode can be used, for example, to allow a delay to continue after the block is bypassed without abruptly cutting off.

For effects like Chorus, Flanger, etc. **MIX = 0%** is the most effective mode when used in a series configuration. Use the Level control to balance the effect volume between normal and bypassed states.

For effects like Delay and Reverb, the **MUTE EFF** or **MUTE IN** modes are usually the most effective as the dry level is unaltered allowing the effect to be turned on or off without changing the direct signal level.

For non-mixable effects such as equalization (Graphic EQ, Wah), distortion (Amplifier) and Cabinet Emulation the bypass mode is one of two states:

- **THRU** : In this mode bypassing the effect effectively turns the effect into a shunt.
- **MUTE** : Mutes the output of the effect.

To bypass an effect press the **EFF BYP** button. Press it again to activate the effect. Effects can also be bypassed remotely using external controllers (i.e. MIDI continuous controllers). If an effect doesn't seem to be doing anything make sure it hasn't been bypassed accidentally. A bypassed effect will have a dotted outline in the layout **EDIT** page and in the effect page the effect name will alternate with the word "BYPASSED"

The rightmost switch on the **MIX** page is labeled **GLBL MIX**. This is the global mix control enable for the block. When on, the mix for this block will be altered by the Global Mix control. This is used to allow overall mixing of effects to compensate for venue differences. For example, you've tweaked your patch "MY MONSTER SOUND" in your rehearsal studio and everyone thinks it sounds great. You then get out to the gig and the effects are too prominent because the room has hard floors and tin ceilings. What do you do? One solution is to frantically edit the patch going through each block and adjusting the mixes. OR... since you previously turned on **GLBL MIX** on the desired effects blocks you have a "master" effects control at your disposal. We'll talk more about the Global Parameters later.

## Output Mixer

The main output has a four channel mixer for fine-tuning a preset's mix. It is accessed from the **LAYOUT** menu on the **MIX** page. Each row in the layout has its own individual level and pan control. The overall level of the preset can be controlled using the **MAIN** slider.

## Attaching Controllers

To attach a controller select the knob that you would like to control and press **ENTER**. If that parameter is capable of being controlled (indicated by the **[ ]** icon below the knob) you will be taken to the **MODIFIER** menu to select the control parameters. See the *Controllers and Modifiers* chapter for more details.

## Saving Presets

All editing in the Axe-Fx modifies data in what's known as the "edit buffer". Upon saving, the contents of the edit buffer are written to a memory location. If a new preset is recalled prior to saving all the edits are lost. Recalling a preset loads the data from that preset into the edit buffer.

To save a preset press the **STORE** button. This brings up the **STORE** menu. The **LOCATION** box contains the preset location at which the edit buffer will be stored. Next to that is the name of the preset currently at that location (if any). If the preset is empty the name will say "**EMPTY**". To save at a different location turn the value dial to modify the location number. To save your changes press the **ENTER** button.

The **NAME** box contains the name of the preset as stored in the edit buffer. To change the name select the character you wish to change with the navigation buttons and turn the value dial to alter the character.

## Recalling Presets

Recalling a preset on the Axe-Fx is done simply by pressing the **RECALL** button and turning the dial until the desired preset is selected.

The Axe-Fx features and “Effects Recall” function. This allows the parameters of an effect in a preset to be copied into the edit buffer. To use this feature simply navigate to the **EFFECT** tab under the **RECALL** menu. Select the preset that you wish to load from and the effect in that preset that you wish to load, and then press **ENTER**. The parameters of that effect will be loaded into the same effect in the edit buffer.

This is useful when you have an effect set up just the way you like it and only want to copy that effect into a preset you are building. Also note that any modifiers that are connected to the effect will be copied as well greatly simplifying preset construction.

# The Effects

The following sections describe the individual effects and their adjustable parameters.

## Noise Gate

The Noise Gate is not a routable effect. It is always connected directly to the main inputs. To edit the effect go to the **GATE** page in the **LAYOUT** menu. The Noise Gate is always active but can be defeated by simply turning the **THRESH** control fully counter-clockwise.

The Noise Gate is a downward expander. Any signal below the threshold is reduced by the expansion ratio. This provides smooth transitions rather than abrupt open/close style gating.


### Parameters

**THRESH** - Threshold control. This sets the level at which the Noise Gate will start its downward expansion. If the input signal drops below this level it will be attenuated by an amount controlled by the ratio.

**RATIO** - Sets the downward expansion ratio. For example, if the threshold is set to -50 dB and the input level is -60 dB and the ratio is 2.0 the input will be attenuated by 20 dB.

**RELEASE** - Release rate control. Sets the rate at which the Noise Gate attenuates the signal once the threshold has been crossed. Higher values will make the signal gradually fade once it drops below the threshold.

## Compressor



The Compressor reduces the dynamic range of the signal by lowering its gain when the input power exceeds a threshold. It is best placed at the start of an effects chain and is most effective when used with clean settings. Using a Compressor with high-

gain distortion can lead to excessive noise or squealing. The Compressor can also be placed near the output of an effects chain if desired to even out the response if using, say, two different distortion types. The low-gain distortion can be followed with a Compressor to even out its response compared to a high-gain distortion. Otherwise the low-gain distortion will be too dynamic.

## Parameters

**THRSH** - Threshold control. The Compressor reduces its gain when the input power exceeds this value.

**COMP** - Sets the gain reduction ratio. This is the ratio of input power to output power beyond the threshold. For example, if the threshold is -40 dB, the input signal is -30 dB and the ratio is 2.0 the output will be -35 dB.

**ATT** - Attack rate. Sets how fast the Compressor reduces its gain once the threshold is exceeded. Higher values equal faster response.

**REL** - Release rate. Sets how fast the Compressor restores the gain once the signal has fallen below the threshold.

**LEVEL** - Sets the output level of the block. This is the same control as on the *MIX* page.

**KNEE** - Sets the "knee" type. A soft knee gradually varies the compression ratio around the threshold whereas a hard knee switches from no compression to the selected compression ratio abruptly at the threshold. With high compression ratios a hard knee may produce undesirable artifacts. In this case set the knee type to **SOFT**.

## Filter

The Filter module is a simple programmable filter designed for general tone shaping. It allows a variety of different filters along with real-time control of the filter parameters. You can use the Filter module for quick, static tone shaping or for elaborate, dynamic tone manipulation.

It can be used as a straight gain block by setting the filter type to NULL. Another possibility is to use it as a treble booster (with more programmability than the one in the Drive module).

In the 60's guitarists began experimenting with booster pedals to increase the signal level into their amplifiers. This increased the amount of distortion their amps would produce. The more popular booster pedals had extra treble boost in addition to overall boost. This technique was essential to Brian May's tone on the early Queen recordings where a treble booster into a Vox AC-30 gave that unmistakable sound.



To use the Filter/Boost module as a treble booster set the **TYPE** to either **HIGHPASS** or **BANDPASS**. Experiment with the **Q** and **FREQ** controls to achieved the desired effect. Increase the level to increase the overall signal level out of the block.

The **FREQ**, **Q**, **GAIN**, **LEVEL** and **PAN** parameters are all controllable. To attach a modifier to these parameters select the parameter and press **ENTER**. This brings up the **MODIFIER** menu. When any of these parameters are attached to a modifier an asterisk (\*) appears after the name indicating such.

## Parameters

**TYPE** - Sets the type of filter. All the standard filter types are available. A **NULL** type has a flat frequency response characteristic.

**FREQ** - Sets the center frequency of the filter.

**ROFFS** - Sets the right channel frequency offset as a multiple of the left channel. A setting of 0.5, for example, would set the right channel frequency to half the left.

**Q** - Sets the 'Q' of the filter. Higher values give sharper responses.


**GAIN** - Sets the gain at the center frequency for the bandpass, notch, low-shelf and high-shelf types. This control has no effect with the other types.

**LEVEL** - Sets the output volume level of the block.

**PAN** - Sets the output panning of the block.

**BYP** - Sets the bypass mode.


## Graphic Equalizer



The Graphic Equalizer is an 8-band equalizer with band centers at 63, 125, 250, 500, 1000, 2000, 4000 and 8000 Hz. Each band can boost or cut up to 12 dB. Simply select the desired band with navigation buttons and use the value dial to vary the gain.

The Graphic EQ can also be used as a booster. To use the EQ as a booster simply emphasize the desired frequencies and set the level as desired. For a treble booster, for example, one might boost the 2K, 4K and 8K by 6 dB or so and turn the level up 12 dB. The parametric equalizers (see below) can be used in the same way by simply turning up the high-shelf gain and increasing the level.

## Parametric Equalizer



The Parametric Equalizer is a 5-band parametric-type equalizer comprised of a low-shelf filter, three bell filters and a high-shelf filter. To edit, select the band desired using the **PAGE** buttons. A graphical display depicts the response.


### Parameters

**FREQ** - Sets the center frequency of the band.

**Q** - Sets the "Q" of the band. Q is a measure of filters bandwidth vs. center frequency. Higher Q's exhibit narrower or sharper response. Use caution as very high values along with high gain can cause output overload and clipping even though the apparent volume is low. Reduce the block output level if this occurs.

**GAIN** - Sets the gain of the filter.

# Chorus



A chorus subtly delays the input signal by a varying amount and mixes it with the undelayed signal. The varying delay slightly detunes the signal so the result is one of multiple instruments playing in unison. The Axe-Fx Chorus is a stereo multi-voice chorus. It uses a very computationally demanding algorithm but delivers exceptionally smooth sounding ensemble effects. Each stereo channel in the chorus can have from one to four voices. Increasing the number of voices increases the fullness of the effect. For classic chorus sounds use two voices (one per side). For thick, full chorus effects use four or more voices.

## Basic Parameters

**VOICES** - Sets the total number of voices used in the effect. For example, a setting of 4 uses two voices per side.

**RATE** - Controls the frequency of the Low Frequency Oscillator (LFO). Use low settings with higher depths for slow moving sounds. Increase the rate for vibrato effects. Set fully CCW to sync the LFO to the Global LFO1 oscillator.

**DEPTH** - Sets the maximum delay variation. Higher depths increase the amount of detuning. Usually the rate and depth settings should be varied inversely, i.e. if you increase the rate decrease the depth however some unique sounds can be obtained using high rates and depths.

**MIX** - Sets the ratio of wet and dry. Duplicated from MIX page. A setting of 50% produces the most prominent effect. Try setting the mix to 100% for vibrato effects.

**TEMPO** - Locks the rate to the global tempo. For example, if the global tempo is 120 bpm and the tempo is set to a quarter note (1/4) then the LFO rate will be 2 Hz ( $120 \text{ bpm} / 60 \text{ seconds} = 2$ ). To ignore the global tempo set the tempo control to **NONE**.

## Advanced Parameters

**BASS** - Adjusts the bass response of the wet signal. The bass can be boost or cut up to 12 dB.

**TREBLE** - Adjusts the treble response of the wet signal. The treble can be boost or cut up to 12 dB.

**BASS FREQ** - Adjusts the corner frequency of the bass control.

**TREBLE FREQ** - Adjusts the corner frequency of the treble control.

**DELAY TIME** - Adjusts the minimum delay time of the delay line. This can provide subtle changes in the character of the effect.


**LFO PHASE** - Adjusts the phase difference between the left and right lfo waveforms. For maximum stereo spread set this to 180 degrees. For a mono chorus simply set this to zero.

**LFO TYPE** - Selects between sine or triangle waveforms for the LFO. Sine is the most commonly used waveform.

**AUTO DEPTH** - When this is set to ON the depth is automatically scaled for the rate. Lower rates therefore increase the actual depth and vice-versa. This greatly simplifies adjusting the rate and depth and gives the most musical results. For wild sounds you may wish to set this to OFF which decouples the controls allowing for full depth swing even at fast rates.

**PHASE REVERSE** - When this is set to ON the phase of the right channel is reversed on the effected signal. This increases the stereo imaging.

## Flanger



A flanger is similar to a chorus but uses a shorter delay time and feeds back some of the effect signal back to the input. It was originally intended to duplicate the sound of two tape decks that were synchronized together and then pressing on the flange of one of the tape reels (hence the term flanging). This caused the tape decks to become slightly out of sync and created the classic wooshing sound. A great example of this is in the Doobie Brother's song "Listen to the Music" during the bridge.

### Basic Parameters

**TIME** - Adjusts the nominal delay time of the delay line. This changes the character of the effect. Low values give a jet-like sound whereas high values are metallic. Adjust to taste.

**RATE** - Controls the frequency of the Low Frequency Oscillator. Use low settings with higher depths for slow moving sounds. Increase the rate for vibrato effects. Set fully CCW to sync to the Global LFO1 oscillator.

**DEPTH** - Sets the maximum delay variation. Higher depths increase the amount of detuning. Usually the rate and depth settings should be varied inversely, i.e. if you increase the rate decrease the depth however some unique sounds can be obtained using high rates and depths.

**FEEDBK** - Sets the amount of wet signal fed back to the input. Increasing the feedback can give the Flanger a metallic quality as it produces sharp resonances in the frequency response. Note that excessive values can result in marginal stability and may even cause oscillation. Decrease the feedback if this occurs.

**MANUAL** - Manually controls the delay time. You can use this along with a foot controller or other controller to control the flange effect. For full manual control set the depth to zero.

**MIX** - Sets the ratio of wet and dry. Duplicated from MIX page. A setting of 50% produces the most prominent effect.

**TEMPO** - Locks the rate to the global tempo. For example, if the global tempo is 120 bpm and the tempo is set to a quarter note (1/4) then the LFO rate will be 2 Hz (120 bpm / 60 seconds = 2). To ignore the global tempo set the tempo control to **NONE**.

### Advanced Parameters

**BASS** - Adjusts the bass response of the wet signal. The bass can be boost or cut up to 12 dB.

**TREBLE** - Adjusts the treble response of the wet signal. The treble can be boost or cut up to 12 dB.

**BASS FREQ** - Adjusts the corner frequency of the bass control.

**TREBLE FREQ** - Adjusts the corner frequency of the treble control.

**LFO PHASE** - Adjusts the phase difference between the left and right lfo waveforms. For maximum stereo spread set this to 180 degrees.


**LFO TYPE** - Selects the waveform for the LFO. Sine is the most commonly used waveform. You can achieve strange rising/falling effects using the sawtooth types.

**LFO HICUT** - Adjusts the filtering of the LFO waveform. For certain waveform types along with extreme depth or rate settings, clicking may occur at the waveform discontinuities. For example a square wave can cause audible artifacts as the LFO rapidly changes from one extreme to the other. Decreasing the LFO FILTER frequency will mitigate this.

**AUTO DEPTH** - When this is set to ON the depth is automatically scaled for the rate. Lower rates therefore increase the actual depth and vice-versa. This greatly simplifies adjusting the rate and depth and gives the most musical results. For wild sounds you may wish to set this to OFF which decouples the controls allowing for full depth swing even at fast rates.

**PHASE REVERSE** - When this is set to ON the phase of the right channel is reversed on the effected signal. This increases the stereo imaging.

## Phaser



A phaser works by cascading a series of "allpass filters" and then mixing the processed signal with the input. The allpass filters cause phase shift and at certain frequencies the amount of phase shift will be exactly out of phase with the input so the mixed signal will have notches at those frequencies. The Axe-Fx Phaser is extremely powerful allowing from 4 to 12 stages along with a feedback control for producing even more dramatic effects. Also, the Axe-Fx phase is full stereo allowing for spatial effects as well.

*NOTE: The **MIX** control should be set at 50% for the maximum effect.*

### Basic Parameters

**ORDER** - Sets the number of stages in increments of two. For classic phaser sounds set the order to four and use low feedback. For more pronounced effects increase the order. Turning this control fully CW puts the Phaser into "Vibe Mode" where the frequency spacings are fixed. In this mode the **FREQ SPAN** control has no effect.

**RATE** - Controls the frequency of the Low Frequency Oscillator. Set fully CCW to sync to the Global LFO1 oscillator.

**DEPTH** - Controls the sweep depth of the LFO.

**RES** - Resonance control. Controls how much of the wet signal is fed back to the input. Increasing the resonance increases how sharp the notches are. Excessive values of feedback can cause instability. If this occurs decrease the feedback.

**FREQ** - Sets the start frequency of the first stage filter. This in combination with the depth control controls the range over which the notches sweep.

**TEMPO** - Locks the rate to the global tempo. For example, if the global tempo is 120 bpm and the tempo is set to a quarter note (1/4) then the LFO rate will be 2 Hz (120 bpm / 60 seconds = 2). To ignore the global tempo set the tempo control to **NONE**.


### Advanced Parameters

**LFO TYPE** - Selects the waveform for the LFO. The ramp types can provide falling or rising effects. Experiment with Exponential or Logarithmic types for pulsating effects.

**FREQ SPAN** - Sets the span of the allpass filters. Higher values separate the resulting notches by greater amounts.

**LFO PHASE** - Sets the phase difference from left to right for the LFO.

## Rotary Cabinet



A Hammond B3 without a Leslie cabinet is like a BLT sandwich without the lettuce and tomato. Guitar players soon came to discover the wonderful tones of the Leslie cabinet and its brethren. The classic Leslie cabinet is comprised of a spinning drum with a slot in it and a rotating horn called a rotor. A low frequency speaker is aimed into the spinning drum while high frequencies are sent to the horn. The result is unmistakable, from schmaltzy hockey-game to Steppenwolf, the Leslie cabinet

became ubiquitous. Spinning drum alone versions have been produced by other manufacturers with Stevie Ray Vaughn's "Cold Shot" being one example of that sound.

The Axe-Fx Rotary Cabinet simulator reproduces all these classic sounds and offers more control. Also, it doesn't weigh 300 lbs and require four guys to move up a flight of stairs. Isn't technology great?

## Parameters

**RATE** - Controls the rate at which the "drum and rotor" spin. Connect this to a controller for real-time control.


**LDEPTH** - Sets the modulation depth of the "drum". Higher settings provide a more pronounced throb.

**HDEPTH** - Sets the modulation depth of the "rotor". To simulate a rotating drum only cabinet reduce this.

**HLEVEL** - Sets the output level of the "rotor". Use this to balance the level between the drum and rotor.

**TEMPO** - **Locks** the rate to the global tempo. For example, if the global tempo is 120 bpm and the tempo is set to a quarter note (1/4) then the LFO rate will be 2 Hz (120 bpm / 60 seconds = 2). To ignore the global tempo set the tempo control to **NONE**.

## Wah-Wah



Ah, the legendary wah effect. No effect has ever been as used (or abused). From Jimi Hendrix's "Voodoo Chile" to, well, Stevie Ray Vaughn's "Voodoo Chile" the wah continues to hold a unique place in the annals of rock history. The Axe-Fx Wah is the embodiment of this legacy but with modern reliability and control. Also, the unique control input processing of the Axe-Fx eliminates the "zipper effect" common to many remotely controlled wahs.



A wah is actually a very straightforward device. The signal is passed through a high-Q filter whose frequency is controllable. The Wah may be placed before distortion for a subtler, classic sound or after distortion for a more prominent and aggressive sound.

## Parameters

**TYPE** - Selects between a lowpass, bandpass or peaking filter. A bandpass filter gives a more dramatic sound whereas the other filters are more subtle.

**FMIN** - Sets the frequency of the filter when the frequency control is at its lowest value. This can be adjusted to match the range of your instrument or preference.


**FMAX** - Sets the frequency of the filter when the frequency control is at its highest value.

**RES** - Sets the resonance, or 'Q' of the filter. Higher values give a sharper response.

**TRACK** - Sets the 'Q' tracking of the filter. As the frequency is increased the resonance will be decreased by an amount proportional to this value. If this is zero the resonance of the filter will be constant at all frequencies. Classic wah pedals usually have a resonance that decreases with frequency due to design limitations. This control can be used to mimic those pedals.

**FREQ** - Sets the frequency of the filter relative to the minimum and maximum frequencies. Normally you would attach this to a controller. Attach it to an external controller (such as pedal) for classic wah or attach it to an LFO or Envelope for autowah or dynamic wah.

## Formant Filter



The wah was originally intended to mimic the sound of the human voice but obviously falls a little short. A formant filter is an extension of the wah principle but operates on the concept of formants. Formants are resonances in instruments,

cabinets, and, in this case, the human vocal tract that give sounds their character. The human vocal tract generates a handful of formants that produce the vowel sounds we recognize. For example the vowel sound "eee" can be reproduced with a bank of narrow bandpass filters with various frequencies and amplitudes. The Axe-Fx Formant Filter allows "talk-box" effects without the fuss and muss of the real thing.

The Format Filter morphs between three vowel sounds: start, mid and end. The **CTRL** knob then controls the morphing between these sounds. For example, we can program the Formant Filter to go "ooo - eee - aaahh" as a pedal is moved. The start vowel is generated with the **CTRL** knob counter-clockwise, the end vowel is generated with the knob fully clockwise and the mid vowel is generated with the knob at 12:00. The sound gradually changes from one vowel to the next between positions.

The Formant Filter usually sounds best when placed after distortion although there are no hard and fast rules.

### Parameters

**START** - Sets the start vowel sound.


**MID** - Sets the mid vowel sound.

**END** - Sets the end vowel sound.

**RES** - Sets the resonance of the filters. Higher resonance can yield a more dramatic effect.

**CTRL** - Controls the morphing between vowel sounds. Normally you would connect this to a controller (i.e. **EXTERN1**).

## Pan / Tremolo



The Axe-Fx Pan/Tremolo provides, as the name would imply, panning and tremolo effects. A panner moves the sound left/right in the stereo field while a tremolo varies the volume. Tremolo can be used to get that classic "surf" sound especially when used with some spring reverb.

## Parameters

**EFF TYPE** - Chooses between the tremolo and panner.

**RATE** - Sets the frequency of the LFO. Turning the control fully CCW locks the rate to the global LFO1 generator.

**DEPTH** - Sets the modulation depth for the tremolo.

**WIDTH** - Sets the modulation depth for the panner. When Width is set to more than 100%, the Panner will pan beyond a normal stereo image

**TEMPO** - Locks the rate to the global tempo. For example, if the global tempo is 120 bpm and the tempo is set to a quarter note (1/4) then the LFO rate will be 2 Hz ( $120 \text{ bpm} / 60 \text{ seconds} = 2$ ). To ignore the global tempo set the tempo control to **NONE**.


**LFO TYPE** - Selects the waveform for the LFO. Try experimenting with the Log or Exp waveforms.

**DUTY** - This controls the symmetry of the LFO waveform. It has no effect if the waveform is a sine wave. For a triangle wave this controls the shape of the waveform. At 50% the waveform is perfectly symmetrical. For a square wave this controls the ratio of time that the waveform is "on" as opposed to "off". This control has no effect for sine, log, exp or random waveforms

**LFO PHASE** - Adjusts the phase difference between the left and right lfo waveforms.

**PAN CENTER** - In panner mode adjusts the apparent center of the stereo image.

## Delay



The real strength of digital processing was first exhibited with the original digital delay processors. Before that delay processing was done using analog delay devices or tape-based techniques. These methods suffered from poor frequency response, noise, and in the mechanical versions, reliability concerns. Digital delays address all of these shortcomings while providing longer delay times.

The Axe-Fx contains two different types of delay blocks. The regular Delay, described here, is your basic digital delay (with a few enhancements). We'll talk about the Multi-Delay later. The Delay has five different modes: Mono, Stereo, Ping-Pong, Dual and Reverse. In Mono mode the inputs are summed and only the left delay line is used. This allows quick, classic delay sounds. The Stereo mode allows independent left and right delay time and feedback allowing for modern stereo delay sounds. The Ping-Pong mode criss-crosses the signal so that the echoes ping-pong left and right. The Dual mode allows full control over the delay block providing controls for all parameters. The Reverse mode is a special mono reverse looper capable of strange and exotic reverse playback effects.

The Delay also contains a lowcut and highcut filter to allow frequency response tailoring of the repeats. By turning down the highcut frequency you can simulate the sound of a tape delay with it's poor high frequency response. Turning up the lowcut frequency can give a thin delay sound for special effects.

The Delay also contains two delay time modulators that can be used to slightly modulate the delay time. These can be used to add depth to the echoes or to simulate an old tape-based echo unit. One can be used, for example, to simulate the slow fluctuation of a worn belt in a tape echo with the other simulating a worn capstan (wow and flutter).

The first and third pages of the Delay menu are the same for all types. The second page of the edit menu changes based on the type of delay selected.

## Common Parameters

**TYPE** - Selects between the various delay types available.

**INGAIN** - Sets the input level into the delay lines. The primary purpose of this is to allow you to attach a controller (i.e. pedal) to control the delay level without disturbing the mix. Set the mix at the desired maximum echo level and then use the INLVL control (via a pedal) to control the echo level. This is different than controlling the echo level with the MIX control since the echoes will continue to sound after the control is set to zero whereas using the MIX control the echoes will be immediately cut off. If you are not attaching a controller then you would normally set this to 100% (default).

**LOCUT** - Sets the cutoff frequency of the lowcut filter. Higher values remove more low frequency content from the delayed signal.

**HICUT** - Sets the cutoff frequency of the highcut filter. Lower values remove more high frequency content from the delayed signal.

**DRIVE** - Sets the drive level into the tube simulator. This can be used to add some distortion to the echo like an old tube-based tape delay. This control has no effect when using the Reverse delay type.

**RATE 1/2** - Sets the rate of the time modulators. The delay time can be modulated so as to simulate a worn capstan or belt or to add a chorus effect to the echoes.

**DEPTH 1/2** - Sets the depth of the time modulators. Use in conjunction with the rate controls.

## Mono Delay

**TIME** - Sets the coarse time of the delay lines. The total delay time is the sum of the **TIME** and **FINE** controls. The time is divided between these two controls to allow either coarse or fine control of the time when using a controller/modifier.

**FINE** - Allows fine tuning the delay time.

**FEEDBK** - Sets the amount of delay feedback. This controls how many repeats are heard.

**ECHO PAN** - Controls the placement of the echoes in the stereo image. Note that this is different than the PAN control on the MIX page which controls the panning of the mixed sound. This control only effects the wet signal.

**TEMPO** - Locks the time to the global tempo. For example, if the global tempo is 120 bpm and the tempo is set to a quarter note (1/4) then the time will be 500 ms (one echo per beat). To ignore the global tempo set the tempo control to **NONE**.

### **Stereo Delay**

**TIME** - Sets the coarse time of the delay lines. The total delay time is the sum of the **TIME** and **FINE** controls. The time is divided between these two controls to allow either coarse or fine control of the time when using a controller/modifier.

**FINE** - Allows fine tuning the delay time.

**RATIO** - Sets the ratio of the delay time of the right channel relative to the left channel. A ratio of 1.0 sets both channels equal. Decreasing this value decreases the delay time of the right channel.

**SPREAD** - Controls the stereo spread of the echoes. Increasing this value increases the separation between the left and right delay signals.

**FEEDBACK L** - Sets the amount of delay feedback for the left channel.

**FEEDBACK R** - Sets the amount of delay feedback for the right channel.

**TEMPO** - Locks the left delay time to the global tempo. For example, if the global tempo is 120 bpm and the tempo is set to a quarter note (1/4) then the time will be 500 ms (one echo per beat). To ignore the global tempo set the tempo control to **NONE**.

### **Ping-Pong Delay**

**TIME** - Sets the coarse time of the delay lines. The total delay time is the sum of the **TIME** and **FINE** controls. The time is divided between these two controls to allow either coarse or fine control of the time when using a controller/modifier.

**FINE** - Allows fine tuning the delay time.

**FEEDBK** - Sets the amount of delay feedback. This controls how many repeats are heard.

**SPREAD** - Controls the stereo spread of the echoes. Increasing this value increases the separation between the left and right delay signals.

**TEMPO** - Locks the delay time to the global tempo. For example, if the global tempo is 120 bpm and the tempo is set to a quarter note (1/4) then the time will be 500 ms (one echo per beat). To ignore the global tempo set the tempo control to **NONE**.

### **Dual Delay**

**TIME L** - Sets the time of the left delay line.

**TIME R** - Sets the time of the right delay line.

**TEMPO L/R** - Locks the delay time to the global tempo. For example, if the global tempo is 120 bpm and the tempo is set to a quarter note (1/4) then the time will be 500 ms (one echo per beat). To ignore the global tempo set the tempo control to **NONE**.

**FEEDBK L->L/R-.R** - Sets the amount of delay feedback for the delay line. This controls how many repeats are heard.

**FEEDBK L->R/R-.L** - Sets the amount of cross feedback for the delay lines. This controls how much of the left delay line is fed back to the right and vice-versa.

**LEVEL L/R** - Sets the volume level of the delayed signals.

**PAN L/R** - Controls the panning of the delayed signals.

## Reverse Delay

**TIME** - Sets the coarse time of the delay lines. The total delay time is the sum of the **TIME** and **FINE** controls. The time is divided between these two controls to allow either coarse or fine control of the time when using a controller/modifier.

**FINE** - Allows fine tuning the delay time.

**FEEDBK** - Sets the amount of delay feedback. This controls how many repeats are heard. Use caution as instability can occur with the reverse type with certain parameter settings.

**ECHO PAN** - Controls the placement of the echoes in the stereo image. Note that this is different than the PAN control on the MIX page which controls the panning of the mixed sound. This control only effects the wet signal.

**RUN** - When this is set to **ON** the reverse playback is active. You can start and stop playback using this or by attaching a controller to it.

**TRIG RESTART** - When this is set to **ON** the reverse playback restarts when triggered via the **RUN** control. If set to **OFF**, the playback continues from the current position.

**TEMPO** - Locks the time to the global tempo. For example, if the global tempo is 120 bpm and the tempo is set to a quarter note (1/4) then the time will be 500 ms (one echo per beat). To ignore the global tempo set the tempo control to **NONE**.


**XFADE TIME** - Sets the crossfade time between reverse audio snippets. When the playback position approaches the delay time a new snippet begins playback at time zero. The crossfade time controls how long it takes for the old snippet to fade out and the new one to fade in. You can achieve interesting and rhythmic variations by setting a long crossfade time. For classic reverse delay sounds set this at or near its minimum value.

## Multi Delay


The Multi-Delay is a rhythmic delay block with five sub-algorithms: Quadtap delay, Plex Delay, Plex Detune, Plex Shift and Band Delay. Delay times can be controlled by tempo allowing for rhythmic patterns to be easily created.

The following diagrams illustrate the various algorithms. Parameters vary by type but are listed together for ease of reference.

### QuadTap Delay




### Plex Delay / Plex Detune / Plex Shift





## Band Delay



### Parameters

**MASTER TIME** - Scales all the delay times. Attach a controller to this for real-time control of the delay times.

**MASTER LEVEL** - Scales all the output levels. Attach a controller to this for real-time control of the echo levels.

**MASTER PAN** - Scales all the pan amounts essentially acting as a spread control. The amount can go negative allowing for the echoes to switch sides. Attach a controller to this for real-time control of the pans.

**MASTER FEEDBACK** - Scales all the feedback amounts. You can attach a controller to this.

**MASTER FREQ** - Scales all the frequency values. Attach a controller to this to vary all the frequency values in real-time. This can be used to achieve a wah-like effect on the echoes.

**MASTER Q** - Scales all the Q values. Attach a controller to this to vary all the Q values in real-time.

**MASTER DETUNE** - Scales all the detune values. Attach a controller to this to scale all the detune values in real-time. By varying the detune values this way, resonances are broken up and the delay becomes smoother.

**MASTER PITCH** - Scales all the shift values. Attach a controller to this to vary all the pitch shifts in real-time.

**DECAY TIME** - Sets the coefficients of the feedback matrix for the Plex types thereby controlling the amount of time for the echoes to fade. Use caution with the Detune and Shift types as high decay times can result in instability.

**DIFFUSION** - Sets the amount of cross-coupling between delay lines.

**TIME** - Sets the delay time of the tap.

**TEMPO** - Locks the delay time to the global tempo. For example, if the global tempo is 120 bpm and the tempo is set to a quarter note (1/4) then the time will be 500 ms (one echo per beat). To ignore the global tempo set the tempo control to **NONE**.

**LEVEL** - Sets the volume level of the tap.

**FEEDBACK** - Sets the amount of delay feedback. This controls how many repeats are heard. The total of all feedbacks must add up to 100% or less.

**PAN** - Controls the placement of the echoes in the stereo image. Note that this is different than the PAN control on the MIX page which controls the panning of the mixed sound. This control only effects the wet signal.

**DETUNE** - Sets the amount of pitch detune for the delay line for the Plex Detune and Plex Shift types.

**SPLICE LEN** - Sets the splice time for the detuners. Longer times are smoother but less precise.

**DIRECTION** - Sets direction of the pitch shifter. Reverse can be used for atmospheric textures.

**SHIFT** - Sets the amount of pitch shift for the delay line for the Plex Shift type.

**FREQ** - Sets the center frequency of the delay line output filter.


**Q** - Sets the 'Q' of the delay line output filter. Higher values result in narrower bandwidth. The Axe-Fx uses a constant power algorithm so higher Q's increase the gain of the filter. As such, use caution as overloads could result with some program material.

**LFO RATE** - Controls the frequency of the Low Frequency Oscillator (LFO). Use low settings with higher depths for slow moving sounds. Increase the rate for vibrato effects. Set fully CCW to sync the LFO to the Global LFO1 oscillator.

**LFO DEPTH** - Sets the maximum delay variation. Higher depths increase the amount of detuning. Usually the rate and depth settings should be varied inversely, i.e. if you increase the rate decrease the depth however some unique sounds can be obtained using high rates and depths.

**LFO TEMPO** - Locks the rate to the global tempo. For example, if the global tempo is 120 bpm and the tempo is set to a quarter note (1/4) then the LFO rate will be 2 Hz (120 bpm / 60 seconds = 2). To ignore the global tempo set the tempo control to **NONE**.

# Reverb



Aside from distortion no effect is probably more important to the electric guitar than reverb. From almost the instant that amplifiers were created, guitarists yearned to be able to duplicate the sound of their amps in a hall or large room. Early reverb simulators incorporated springs or large metal plates. Most fine recording studios had their own large rooms dedicated to providing reverb. A speaker and microphone were placed in the room and the reverberated sound was recorded.

Digital processing excels at simulating reverberation and the Axe-Fx has one of the finest reverbs you've likely heard. A proprietary bandpass comb-filter algorithm provides extremely dense and smooth reverbs with no graininess or metallic qualities. The Axe-Fx provides five basic reverb types: Spring, Room, Hall, Chamber and Plate.

The Spring reverb type simulates the sound of the old spring reverbs used in popular guitar amplifiers (except for the crashing sound when someone trips over it). It is characterized by a smooth tail with a slightly "boingy" quality. For surf and rockabilly dial up the Spring reverb, plug in your Strat or Tele and lay down some Dick Dale.

The Room reverb type simulates an actual room. It is the type to use when you want the most natural, realistic reverb. Also great on vocals and percussion.

The Hall reverb type is similar to the Room reverb but simulates a concert hall. It is a little less smooth and has some response peaks lending it a unique character. Use this when you want your sound to stand out a little.

The Chamber reverb type simulates the sound of large, boxy chamber. It is useful when you want a bright, resonant reverb sound.

The Plate type simulates the sound of a vintage reverb plate. These are large metal plates suspended in a frame. An acoustic signal is launched into the plate and pickups record the sound that is produced as it bounces around inside the metal.

Plate reverbs are characterized by their smooth yet bright sound and were popular in the 70's and 80's especially for vocals. The Axe-Fx Plate simulation captures the "shiny" sound of a plate reverb but without all the complicated setup.

The Axe-Fx Reverb edit menu has three pages. The basic page has the most commonly used of the parameters below. The mix page is the standard mixer. The advanced page allows for more in-depth editing and contains all the adjustable parameters (except for the mixer parameters).

## Parameters

**TYPE** - Selects the reverb type. There are five basic types with three variations for each type, small, medium, and large. Each type sets the parameters below to a preset value. You can override the parameter values afterward but if you then change the type the values will be reset to the default values for that type.

**TIME** - Sets the reverb decay time. This is the amount of time for the reverb to vanish beyond the point of perception. This is known as the t60 time, referring to the amount of time required for the reverb to decay to 0.001 of its initial value (-60 dB).

**SIZE** - Sets the size of the spring, room, hall etc. This controls the length of time it takes for an echo to bounce between the walls. Increasing this increases the echo time and also increases the delay before the reverb starts. Small values smooth out the reverb, very small values can be used to obtain a metallic sound. Large values can make the reverb more grainy as the time between the individual repeats increases. Also, as the size is increased the reverb will become somewhat darker as the high frequencies are absorbed more.

This control is important in that it actually sets the size of the room, hall, etc. that is simulated by the algorithm. If you want the reverb to sound like a huge concert hall then best results will be obtained by increasing this value. Of course there are no rules and you can set the size small and the time high to obtain some interesting effects.

**INLVL** - Sets input level to the reverb. Primarily for use with a controller to control the reverb and allow the reverb to continue to sound. Set to 100% normally. Attach a controller to vary the reverb level without disturbing the mix.

**LOCUT** - Decreases the low-frequency content of the wet signal

**HICUT** - Decreases the high-frequency content of the wet signal

**COLOR** - Sets the color of the reverb. Higher values simulate less high-frequency wall absorption and result in a brighter reverb.

**DIFFUSION** - Controls the density of the reverb tail. Higher values give a smoother sound. Lower values allow the individual repeats to be more easily discerned.

**PRE DELAY** - Adds extra delay before the reverb starts. The **SIZE** control automatically imparts a certain amount of delay before the reverb starts. Use this control to add more delay if desired. For example, if the SIZE is low the reverb will start almost immediately. You can use this control to add some delay before the reverb starts but keep the small sounding size.

**EARLY DELAY** - This controls the relationship between the early reflections and the reverb tail. This allows a +/- 50% change in the early reflections initial delay. The size control automatically sets the time between the early reflections and the tail. You can use this control to vary that time.

**EARLY LEVEL** - Adjusts the relative volume level of the early reflections. This control has no effect for the Spring reverb type.


**REVERB LEVEL** - Adjusts the relative volume level of the reverb tail.

**MOD DEPTH** - This parameter controls the depth of modulation of the reverb tail. For a more musical sound experiment with this and the **MOD RATE** control. The reverb contains an LFO that modulates the delay lines that comprise the reverb. This modulation helps fill out the soundstage and makes the reverb sound fuller. The modulation is best used on pitched instruments. For percussive instruments (i.e. drums) it may sound better with the modulation off. Set the depth to zero to defeat the modulation. To hear the effect of the modulation turn the mix to max and adjust the depth and rate, then set the mix to the desired amount.

*NOTE: The modulation depth defaults to zero. To use the modulation you must enter the advanced parameter page and set the depth and rate as desired.*

**MOD RATE** - This parameter controls the rate of modulation of the reverb tail.

## Amp Simulator



Without distortion the electric guitar probably wouldn't have had nearly the impact it has had on popular music. The Axe-Fx contains multiple distortions based on emulations of various amplifiers. As mentioned earlier the Axe-Fx is not a modeler however these emulations provide sonic characteristics very similar to the amplifier they are emulating.

One of the primary differences between the Axe-Fx and a modeling amplifier is the control philosophy. Modeling amps replicate the operation of the tone, volume, drive, etc. controls even replicating the annoying interaction among these controls. The Axe-Fx philosophy is to provide the control as a more useful tool rather than a strict replica of the original. In this regard the tone controls on the Axe-Fx are true cut/boost equalizing controls and do not interact. Because of this the controls are more powerful and are set differently than on a typical amplifier. "Diming" all the tone controls may sound great on an old tube amp but usually gives less the optimum results with the Axe-Fx.

The Axe-Fx distortion is based on a proprietary dual-stage non-linearity generator. There are two basic stages: preamplifier and power amplifier. The preamplifier stage emulates the distortion generated by classic tube preamplifiers. The power amplifier stage emulates the type of distortion generated by a tube power amplifier using our proprietary Dynamic Response Technology™.

Full control over all parameters is naturally afforded allowing precise tailoring of this all-important block to your particular sonic tastes. Read the following carefully as the distortion block in the Axe-Fx is very sophisticated and a complete understanding will allow you to get the most from it. Also it is important to understand the role of the Cabinet Simulator in the overall sound. The cabinet contributes to the sound of a preset at least as much the amplifier type. If you're not getting the exact sound you're looking for try a different cabinet simulation. Of course there are no "rules" so there's nothing preventing you from using a 10" blues cabinet with a high-gain amp simulation. Experimentation can lead to some unique and useful sounds.

## Parameters

**TYPE** - Selects the amplifier simulation. The simulations are based on classic and modern amps as well as some hybrids and completely original types that we concocted. The following types are available:

- **Tube Pre** - A completely neutral, low-gain tube pre-amp simulation. Useful for warming up vocals and other instruments.
- **Jazz** - Based on a Japanese solid-state amp with built-in chorus. With essentially no tone shaping this amp has a warm, midrange-thick sound that is good for jazz and fingerstyle. With the Axe-Fx's powerful tone controls you can tweak this type to get shimmering rhythm tones as well.
- **Brownface** - Based on a classic American 40-watt tube amp with built-in vibrato. Great for gutsy blues, this type breaks up nicely, especially when the Master is cranked. The original had no Mid or Presence so set these to '0' for classic tone.
- **Blues** - A low-to-medium gain sound great for blues. Based on a classic bass amplifier with four 10" speakers, it didn't work so well for bass but guitar players quickly discovered it made a great blues amp. Try a treble booster in front for screaming blues work a la Albert Collins or Albert King.

- **Tweed** - Based on a small, low-power, tweed-covered amp. The original had no controls other than volume. Set all tone controls to '0' for authentic tone. Adjust as desired to venture into new sonic territory. Our simulation has a bit more gain than the somewhat anemic original to allow you to dial in a nice crunch. To recreate the original faithfully set the drive to about 6 and use the Master as the volume.
- **Blackface** - Based on a popular, 100-watt American tube amp with two 12" speakers. This simulation captures the Normal Channel. Very similar to the Brownface model but a little more mellow. The tone-stack is also slightly different giving it just a bit different voicing.
- **Class A** - A medium-gain emulation based on an early British tube amplifier. This type does not have the high-frequency emphasis like the American types and therefore has a darker sound. Try a treble boost in front for a snarling British "opera-rock" sound. This amp is notable in that it has no negative feedback around the power-amp and hence has a gritty character and less high-frequency response.
- **Top Boost** - Based on the "Top Boost Mod" version of the Class A. The public yearned for a brighter amp and the designers responded by adding a treble boost circuit. At first this circuit was a retrofit but then included as standard. Our simulation captures the boosted high-frequency response and slightly reduced bass response of the original.
- **Plexi** - Based on a classic British amp, the Plexi is great for crunchy rhythm work. The original was basically a copy of the 4x10 bass amp (see Blues type above) that guitar players adopted but with EL34 output tubes and other British components. Despite being essentially a copy it had a unique voice all its own. It has somewhat low preamp gain and works best with the Master and Drive both set fairly high.
- **Brit 800** - The successor to the Plexi type was the vaunted 800 series lead amplifier. Many 80's rock hits were born using this amp and we've captured its tone and put it into a neat little package. This amp had EL34 output tubes, some treble peaking on the input and a little more gain than the Plexi. Like the Plexi type it likes having the Master cranked. At low Master settings the amp can be brittle but bring the Master up and the true tone of this beast comes out. Try it with any of the 4x12 cabinet types for classic rock and metal tones. Try a drive block in front for more snarl.
- **Brit 900** - The successor to the 800 series was the 900 series. This amp had basically the same power amp but a new preamp with more tone shaping, more gain, and a solid-state clipping circuit that gave it a raspier sound. This amp was designed to get more of its distortion from the preamp than the earlier models but you can still keep the drive low and turn up the Master for more power amp distortion.
- **Brown** - Based on a modified British style head with plenty of gain and lots of mids and highs. This type captures the sound of Eddie's early work. Crank the Master and bring the drive up until you reach sonic nirvana.

- **Boutique 1** - A medium-gain, thick, yet crisp, sound with a fair amount of power amp breakup. Based on a now-defunct amplifier that was renowned for its liquid tone and endless sustain. This amp had very unique tone controls and as a result a distinctive voice with a bell-like quality. The preamp gain is fairly low so crank the Master to get that gutsy crunch. Good for rhythm work in a sparse situation where fullness of tone is required.
- **Boutique 2** - Same as Boutique 1 but with more gain and a bit more high-frequency emphasis. The lead version of Boutique 1.
- **HiPower I** - A medium-gain, full sound based on a famous “High Wattage” amp. These amps had a unique tone-stack and industrial quality output transformers with tremendous frequency response. Chimey with a bit of power amp breakup. Plug in your Tele and crank out some Baba O'Reilly.
- **HiPower II** - Like HiPower I but using the “Brilliant” channel.
- **USA Clean** - A somewhat neutral clean sound that can be pushed into gentle clipping. Based on a classic California amp's clean channel this type has a full tone with a gentle midrange dip. The power amp is punchy and clean but can be driven into light distortion if desired. Sounds best with the drive turned up fairly high.
- **USA Rhy 1** - Crunchy California rhythm sound. Effective for solo use too with the gain turned up.
- **USA Rhy 2** - Similar to USA Rhy 1 but with the “mid-boost” engaged. This effectively removes the midrange dip from the tone stack and gives a more focused sound and a bit more gain.
- **USA Lead 1** - A tight, focused, hi-gain sound great for fusion and rock leads. Based on a modern Californian lead amp that set the standard for hi-gain lead tones. With the tone-stack before the preamp tubes this type has a more liquid response than the British types where the tone-stack is after the preamp. For the classic California lead sound turn the drive up and back of the Master a bit so that most of the distortion is coming from the preamp.
- **USA Lead 2** - Similar to USA Lead I but with the “treble shift” engaged. This shifts the response of the treble control lower and gives a slightly different character to the tone. There is also a “treble peaker” on the input stage which slightly boosts the high frequencies giving this type a little more “cut”.
- **Recto 1** - Based on a diamond-plated monster that redefined hard rock and “nu-metal” this type is characterized by a big bottom and some top-end sizzle. The tone-stack location is after the preamp which is quite a departure from the earlier Californian amplifiers.
- **Recto 2** - Similar to Recto I but with a slightly different input frequency shaping circuit.
- **Solo 100** - Based on a high-gain hot-rod with a chrome chassis, this amp is noted for its snarling lead sound. Also great for aggressive rhythm work, this type “chugs” nicely without getting muddy. Pair it with one of the 4x12 cabinet simulations for modern rock tones.



- **Spec. OD 1** - Based on a coveted but rare lead head that was made famous by Larry Carlton and others. Another amp with a very strange tone-stack, this amp has a singing voice and is great for modern blues/fusion work. This is the clean channel.
- **Spec. OD 2** - The overdrive channel of the above.
- **Euro 1** - Based on a German high-gain amp, these amps pay homage to the British amps but with lots more gain and more high-frequency emphasis. This type simulates the overdrive channel with the boost and “structure” switches off.
- **Euro 2** - As above but with the boost and structure switches on. This one has lots of gain and plenty of low-end chunk along with a crispy top-end. Great for modern metal.
- **UK GC30** - Based on a great British amp introduced in the 90’s this amp is a strange marriage of a USA style pre-distortion tone-stack, British voicing and a Class A power amp. Best for blues and lower-gain rock leads, has nice sustain qualities. Can get muddy at high drive levels, decrease the bass to compensate.
- **Buttery** - Based on an 18-watt amp that gained notoriety during the late 90’s this type is a low-gain amp that relies mostly on power amplifier distortion. Try a drive in front for smooth lead sounds.
- **Metal** - A custom type similar to a British type but with more gain for more grind. This simulation features quite a bit of high-frequency emphasis along with a modified British tone-stack. Capable of searing rhythm and lead tones.
- **Big Hair** - Spandex, studded wrist bands, pyrotechnics and your Axe-Fx are all you’ll need to relive the 80’s metal scene. This custom type has a unique voicing and tone-stack that emphasizes mid frequencies without getting muddy. Now plug in and shred!
- **Hellbeast** - A radical custom type with an unconventional tone-stack.
- **Supertweed** - Like a vintage Tweed amplifier on steroids.
- **Fusion** - A smooth, thick tone good for fusion/blues solo work.
- **FAS Clean** - Combines the best features of the Blackface and the USA Clean into a hybrid clean tone that’s great for a variety of uses.
- **FAS Crunch** - A hybrid British/USA crunch sound.
- **FAS Lead 1** - A neutral high gain lead with a tight midrange.
- **FAS Lead 2** - More gain and more sizzle.
- **FAS Modern** - A high gain hybrid tone that’s equally suited to modern rhythm and lead work.
- **JR Blues** - Based on a modern all-tube combo amp with two EL84 output tubes and a single 12” speaker. This amplifier has become an instant classic because of its gutsy tone at manageable volumes.
- **Brit Pre** - Based on a rack-mount preamplifier version of the **Brit 900**. The preamp gained notoriety for its crunchy tone and was made popular by ZZ Top.

**BRIGHT** - Many amplifiers contain a “treble peaker” on the volume or drive control (see **DRIVE** below). Some amplifiers have a “bright switch” that can be used to engage or disengage the circuit. On many amps this switch is built in to the volume control as a “pull on” switch. On others the circuit is hard-wired.

The Axe-Fx amp types default to a particular state for the bright switch. If the amp had a hard-wired treble peaker the default state is on. If the amp had no circuit at all the default state is off. You may override this state by selecting the **DRIVE** control and pressing **ENTER**. This will toggle the state of the switch. The text “BRIGHT” will appear under the control when the bright circuit is active.

If the original amp did not have a treble peaker circuit, the bright switch uses circuit values most suited to an amp of that type. On some amps the effect may be subtle, on others, quite pronounced.

**DRIVE** - Sets the preamp drive. Higher settings equal more preamp distortion. On some amplifier types the drive control has a treble peaker (like the original). When the drive is turned down the low frequencies are attenuated more than the high. As the drive is turned up the low frequencies are increased more.

Many amplifiers have this feature and it can be heard as the drive is varied. You can use this to achieve the exact sound you’re looking for when a drive block feeds the amp. Adjust the drive control of the amp to achieve the desired amount of input treble peaking and then adjust the drive and the output level of the drive block to achieve the desired amount of distortion.

The Drive control has 40 dB of range. At a setting of ‘0’ the gain is 40 dB below the maximum gain.

**BASS, MID, TREB** - Tone controls. The tone controls in the Axe-Fx have up to twice the range of a typical amplifier. When a tone control is set to the 12:00 position (0.0 dB) it is equivalent to the simulated amplifiers control at 12:00. However, the boost cut range of the control is greater, +/- 12 dB, whereas a typical amplifier may have only +/- 6 dB or less. This allows you to get sounds, like heavily scooped mids or boosted treble, that normally wouldn’t be possible.

Also, the tone controls do not interact like a typical amplifier. So when you turn the treble control the midrange and bass are not affected. This makes dialing in a certain tone easier and quicker than with a typical tone stack. This does not affect the voicing of the simulation in that the frequency response of the original circuit is always achieved however the exact setting of the controls will be somewhat different. In general the Axe-Fx tone controls are more sensitive than a typical amp and require less extreme settings to achieve the same sound. For example, if you set the treble to full on a British hi-gain amp, the corresponding setting on the Axe-Fx is about 5.0 dB. The advantage of this philosophy is ease of use plus more flexibility and wider range of tones. Adjust the tone controls slowly and listen carefully. A 1.0 dB adjustment can make a marked difference in the tone.

Some of the amps simulated do not have the full complement of tone controls. In those cases setting the control to 12:00 replicates the original. For example, some early amps did not have Mid controls. To capture the original faithfully simply set the control to '0'. Adjust the control as desired to achieve new and different tones.

Be careful in setting the tone controls as extreme settings along with high gain can cause pickup squealing or excessive noise.

**PRES** - Power amp presence control. This control boosts (or cuts) the upper frequencies from the power amp simulator by varying the negative feedback frequency response. Increasing this can help your sound “cut” through a heavy mix. This control actually has a greater range than a standard presence control. Values greater than zero behave like a typical tube amp, values less than zero actually reduce the high-frequency response even further.

If the Damping is set to zero this control is converted to a high-shelf equalizer at the output of the power amp. This allows you to control the high-frequency response of the power amp for types that don't have any negative feedback.

**HI CUT** - This control sets the cutoff frequency of a lowpass filter at the very end of the preamp simulation. It defaults to a preset value for each amp type but can be overridden if desired. Experiment with this to fine tune your tone. For example, some of the higher gain types are characterized by fairly heavy filtering after the preamp stage but with this control you can reduce the amount of filtering and achieve a brighter tone. Conversely you can reduce this value to achieve a darker or less brittle tone.

If using the Axe-Fx along with a separate tube power amp you may wish to experiment with this control to achieve the desired tone as the power amp may have its own high-frequency filtering.

**DEPTH** - This controls the effective output impedance of the power amp simulation. Higher values increase the impedance which increases the interaction of the virtual speaker with the power amp. Higher values give a fuller, looser sound, while low values can be used to achieve a more focused sound.

**DEEP** - Selecting the **DEPTH** control and then pressing **ENTER** toggles the state of the **DEEP** switch. When the **DEEP** switch is active the negative feedback around the power amp is modified and the power amp will have enhanced low-frequency response adding depth and punch to the tone. This control defaults to off whenever a new amp type is chosen.

**DAMP** - This controls the amount of negative feedback, or damping, in the power amp simulation. Higher values give a tighter and brighter sound but can sound harsh at very high master volume levels. Lower values give a loose and gritty sound and feel. Each amp type defaults to its own value but you may override the default value with this control. For example, a Top Boost amp has no negative feedback and as a result a unique tonal character. You can override the default damping and dial in some negative feedback to give the power amp a more “American” sound but still retain the preamp voicing.

**SAG** - This controls how dynamic the power amp simulation behaves. Higher settings simulate higher power supply impedance and thus more droop in the tube plate voltages which leads to a more compressed feel.

This control interacts with the Master Volume control in that at low Master Volume settings this control will have little effect as the power amp is not being pushed. As the power amp is pushed and draws more virtual current from its virtual power supply the Sag control will have more effect.

*NOTE: Turning this control fully CCW defeats the power amp simulation. If you are using the Axe-Fx into an external tube power amp and cabinet you may want to set this control to zero to defeat the power amp simulation.*

**MASTER VOL** - This, the Master Volume, is a very important control. It determines the drive to the power amp simulator. A higher setting increases the distortion contributed by the power amp simulator. As the Master is turned up the entire character of the amp will change, just like the real thing. The tone controls will have less influence on the sound, and the sound will “bloom” more and be more touch sensitive.

By carefully balancing Drive and Master Volume you can achieve the tone you desire. Experiment with the two to achieve your ultimate tone. Sometimes the tone you desire may be mostly preamp based and as such turn the Drive up and the Master down. Other times the tone may be mostly from the power amp so crank the Master up and back off the Drive. Amps with negative feedback (damping greater than zero) tend to have a crunchier power amp distortion and this can even get raspy if driven too hard. This is due to the negative feedback attempting to linearize the power amp. The resulting transfer function is harsher at clipping than an amp with little or no feedback. You can experiment with the damping control and master volume to achieve the desired power amp distortion timbre.

If the Master Volume is set very high best results are usually achieved by reducing the drive control. Try setting the Master around 9 or so and then slowly bringing the drive up until the desired tone is achieved. At high Master settings less drive is usually required, especially for high-gain types.

Amp types that are designed for preamp distortion typically sound better with lower values of this control and too high of a value can make the tone muddy or excessively noisy. This includes the USA Lead types, SOLO 100 and others. Lower gain amps such as Plexi, Brownface, and others can benefit from higher settings as this can reduce the harshness of the amp.

If the power amp simulation is off (Sag at zero) this control then becomes a simple level control. This control has 40 dB of range. A setting of ‘5’ is therefore 20 dB less than maximum.

**LOWCUT FREQ** - This control allows you to reduce the amount of low frequency content at the input to the amp simulator. This parameter defaults to a value for each type but can be overridden if desired.

**TONE FREQ** - This control allows you to alter the center frequency of the tone controls. You can use this to change the character of the preamp. This parameter defaults to a value for each type but can be overridden if desired.

**XFORMER LF** - This control allows you to alter the lower cutoff frequency of the “output transformer”. Increase this value to simulate an old, under-designed transformer as was common in some vintage amps. This parameter defaults to a value for each type but can be overridden if desired.


**XFORMER HF** - This control allows you to alter the upper cutoff frequency of the “output transformer”. Decrease this value to simulate narrow bandwidth transformers as were common in some vintage amps. This parameter defaults to a value for each type but can be overridden if desired.

**TONE LOCATION** - This control allows you to alter the location of the tone stack. “Pre” places the tone stack at the input to the amp, “post” places the stack between the preamp and power amp. This parameter defaults to a value for each type but can be overridden if desired.

**PRESENCE FREQ** - This control allows you to alter the center frequency of the presence control. This parameter defaults to a value for each type but can be overridden if desired.

**LEVEL, PAN, BYP MODE** - These are the standard output mixer controls.

## Cabinet Simulator



The Axe-Fx contains 20 cabinet simulations. These simulations recreate the tonal characteristics of a variety of different speaker and cabinet configurations. More than just simple filters, the cabinet simulator actually captures the subtle frequency response variations inherent in a real guitar speaker.

The simulator is true stereo allowing different speaker/mic combinations for each channel. This allows setting up a dual amp configuration easily. Simply run AMP1 with its pan control fully left and AMP2 with its pan control fully right. Sum their outputs into a cabinet block and set the left cabinet and mic types for AMP1 and the right cabinet and mic types for AMP2.

## Parameters

**TYPE L/R** - Selects the cabinet simulation. The following simulations are available:

- **1x6 Oval** - 6x9 oval (like in an automobile) speaker used in some early amplifiers. Match this up with a Plexi model and crank out some Zep.
- **1x8 Tweed** - Single 8" speaker. Good match for the Blues distortion. Really thin and cutting for roots blues leads.
- **1x10 Gold** - Single 10" Vintage speaker.
- **1x10 Blue** - Single 10" Alnico "Blue" speaker.
- **1x12 Tweed** - Based on the original 12" speaker used in the early "Tweed" amplifiers.
- **1x12 Black** - Based on the single 12" speaker used in the "Blackfaced" tube amps.
- **1x12 Brit** - Based on the single 12" speaker used in the British tube amps.
- **2x12 Black** - Based on the dual 12" speaker cabinet used in the "Blackfaced" tube amps.
- **2x12 Brit** - Based on the dual 12" speaker cabinet used in the British tube amps.
- **2x12 Cust** - A "custom" dual 12" speaker cabinet emulation based loosely on the evaluation of various "Boutique" amplifiers.
- **4x10 Bass** - Based on the venerable "Tweed Bassman" amplifier.
- **4x12 Recto** - Matches up nicely with the Amp Simulation of the same name for that chunky, mid-scooped sound.
- **4x12 Brit** - Based on the sound of modern British cabinets equipped with "vintage" mid-power drivers.
- **4x12 20w** - Captures the essence of the early British 4x12 speaker cabinets with their low-power drivers and unique response.
- **4x12 25w** - Based on the sound of the British 4x12 cabinets prevalent in the 1970's.
- **4x12 75w** - Based on the sound of the British 4x12 cabinets prevalent in the 1980's. A good match for the Metal or Hellbeast Amp Simulations.
- **4x12 30W** - Based on the sound of a newer 4x12 cabinet with reissue 30W speakers.
- **1x8 Blue** - Based on the sound of a classic American 8" speaker with a blue label.
- **1x12 Blue** - Based on the sound of a classic American 12" speaker with a blue label.
- **2x12 Blue** - Based on the sound of two classic American 12" speakers with blue labels.

**MIC L/R** - Selects the microphone simulation type. There are eight different types based on classic microphones that are popular for micing guitar cabinets.

**LINK** - When ON, the right channel speaker and mic type change when the left channel type is changed allowing for quick evaluation of the various types. You can still override the right channel types if desired.

**LEVEL L/R** - Sets the output level for the left and right speaker/mic.

**PAN L/R** - Sets the output panning of the speaker/mic. Each speaker/mic combo can be panned in the stereo field. By default they are panned 25% from full left/right. Adjust this control to obtain the desired amount of separation.

## Drive

The drive block replicates the effect of classic “stomp boxes”. They range from sublime to intense. Use caution when putting a drive before a high-gain amp as excessive noise and squealing may occur. Drives work best before low and medium gain amps.

### Parameters

**TYPE** - Selects the type of drive effect. The fuzz types are based on a hard-clipping distortion and give a raspy sound. The overdrive (OD) types are based on a cold-cathode tube model and give a warm, mellow overdrive tone. The boost types don’t distort much unless the drive is set quite high and are primarily tone-shaping and overdrive devices. The distortion types (dist) are based on a variety of tube and solid-state models and give classic distortion tones. The following types are available:

- **Rat Fuzz** - Based on a high-gain, raspy fuzz good for searing lead work.
- **PI Fuzz** - A more mellow but fuzzy distortion sound
- **Tube OD** - A fairly neutral distortion sound with just a bit of low-frequency roll-off.
- **Super OD** - Midrangey, honking tone with a good snarl.
- **Treb Boost** - A bright, trebly sound good for overdriving medium gain amps. Particularly effective on darker amps like Class A. This type has a LOT of treble boost and can easily cause pickup squeal when used with a high-gain amp type.
- **Mid Boost** - A custom mid-boost overdrive.
- **Tube Dist** - A screaming distortion sound good for overdriving low gain amps. Based on the legendary Japanese pedal used by many famous artists.
- **Fat Dist** - A thick, medium gain distortion sound with a low-midrange emphasis.
- **Cust Dist** - Based on a “modified” **Tube Dist** type. This type captures the most popular mods done to the famed Japanese distortion pedal. Sounds great as a clean boost in front of a low gain amp with the drive turned down and the level turned up.

- **Oct Dist** - An octave distortion effect. This produces an octave above the note you are playing. For best results use your neck pickup and constrain your playing to the 12th fret and above.

**DRIVE** - Sets the input drive level.

**TONE** - Controls the tone of the effect.

**LEVEL** - Sets the output level of the block

**BYP MODE** - Selects the bypass mode of the block.

## Pitch Shifter

The Axe-Fx Pitch Shifter has 6 basic modes of operation: Detune, Fixed Harmony, Intelligent Harmony, Whammy, Octave Divider and Crystals. The mode is selected on the **TYPE** page.

The Pitch Shifter can use one of two different algorithms when in the Fixed Harmony or Whammy modes. The algorithm is selected using the **NOTE TRACK** control. When set to **ON**, the Pitch Shifter will track the pitch of the incoming note and adjust various internal parameters accordingly. This mode provides reduced latency but naturally only works with single notes. Setting **NOTE TRACK** to **OFF** selects the multi-voice algorithm which allows pitch shifting not only single notes but chords as well. In this mode the **TRACKING** control can be used to achieve the best compromise between sound quality and latency.

### Detune

The Detune mode creates two voices that are slightly detuned from the input. The amount of detuning is adjustable between -50 and +50 cents. This mode is useful for creating double-tracked sounds or chorus-like effects.

**V1,2** - Sets the detune amount for each voice. Attaching an LFO to these can be used to create chorus effects.

**LVL1,2** - Sets the volume level of the voice.

**PAN1,2** - Sets the panning of the voice.

### Fixed Harmony

The Fixed Harmony mode creates two voices that are fixed intervals from the input.

**VOICE1,2 DETUNE** - Sets the detune amount of the voice in cents. The range of +/- 50 cents. You can attach a controller to the detunes by pressing enter.

**VOICE1,2 SHIFT** - Sets the shift amount of the voice in half-steps. The range of shift is +/- 12 half-steps.

**VOICE1,2 LEVEL** - Sets the volume level of the voice.

**VOICE1,2 PAN** - Sets the panning of the voice.



**VOICE1,2 DELAY** - Sets the delay time of the as a function of the tempo.

**VOICE1,2 DLYTEMPO** - Locks the delay time to the global tempo. For example, if the global tempo is 120 bpm and the tempo is set to a quarter note (1/4) then the time will be 500 ms (one echo per beat). To ignore the global tempo set the tempo control to **NONE**.

**VOICE1,2 FEEDBACK** - Sets the feedback of the voice to the input. By delaying and feeding a voice back strange pitch effects can be created as the note is translated pitch again and again.

**NOTE TRACK** - Setting this to **ON** instructs the pitch shifter to track the pitch of the input. For single note work this provides improved results. For chordal work this should be set to off as the pitch tracker obviously cannot determine the pitch of simultaneous tones.

**TRACKING** - When **NOTE TRACK** is set to **OFF** use this to fine tune the sound of the pitched note.

## Intelligent Harmony

The Intelligent Harmony mode creates two voices that track the note you're playing and remain within the key.

**KEY** - Sets the key that the harmony will be in.

**SCALE** - Sets the type of scale that the harmony will use. Choices are **MAJOR**, **HARMONIC MINOR** and **MELODIC MINOR**

**MODE** - Sets the mode of the scale that the harmony will use. For example, to play in A minor, which is the sixth mode of the major scale, set the key to 'A' and the mode to '6'.

**VOICE1,2 HARMONY** - Sets the scale degree the voice will sound.

**VOICE1,2 DELAY** - Sets the delay time of the voice in milliseconds.

**VOICE1,2 DLYTEMPO** - Locks the delay time to the global tempo. For example, if the global tempo is 120 bpm and the tempo is set to a quarter note (1/4) then the time will be 500 ms (one echo per beat). To ignore the global tempo set the tempo control to **NONE**.

## Whammy

The Whammy mode allows control of the pitch shift via a control knob (normally you would connect this knob to a controller such as an expression pedal). There are two sub-modes: Whammy-Up and Whammy-Down. The difference between the sub-modes is the direction of the pitch shift. In Whammy-Up mode the pitch increases as the control is increased. In Whammy-Down mode the pitch decreases as the control is increased.

**MODE** - Selects the Whammy mode: UP or DOWN.

**CONTROL** - Adjusts the output pitch. Attach to a controller for dynamic control of the pitch.

**NOTE TRACK** - Setting this to **ON** instructs the pitch shifter to track the pitch of the input. For single note work this provides improved results. For chordal work this should be set to off as the pitch tracker obviously cannot determine the pitch of simultaneous tones.

**TRACKING** - When **NOTE TRACK** is set to **OFF** use this to fine tune the sound of the pitched note.

## Octave Divider

The Octave Divider creates two new notes one and two octaves below the input. This effect simulates the classic effect and works by actually turning the input into a square wave and then dividing the signal by two using flip-flops. Like the classic effect, this effect only works on single notes and works best on notes above the fifth fret. Experiment with pickup selection and effect placement to achieve the best results.

**LVL1,2** - Sets the volume level of the octaves.

**PAN1,2** - Sets the panning of the octaves.

**MIX** - Sets the mix between the effect and input.

## Crystals

The Crystals pitch shifter is similar to the Fixed Harmony but optimized for special effects. It features much longer possible “splice” times allowing for interesting delay effects. It also features a reverse switch and extensive tempo options.

**VOICE1,2 DETUNE** - Sets the detune amount of the voice in cents. The range of +/- 50 cents. You can attach a controller to the detunes by pressing enter.

**VOICE1,2 SHIFT** - Sets the shift amount of the voice in half-steps. The range of shift is +/- 12 half-steps.

**VOICE1,2 LEVEL** - Sets the volume level of the voice.

**VOICE1,2 PAN** - Sets the panning of the voice.

**VOICE1,2 DELAY** - Sets the delay time of the voice in milliseconds.

**VOICE1,2 DLYTEMPO** - Locks the delay time to the global tempo. For example, if the global tempo is 120 bpm and the tempo is set to a quarter note (1/4) then the time will be 500 ms (one echo per beat). To ignore the global tempo set the tempo control to **NONE**.

**VOICE1,2 SPLICE** - Sets the splice time of the voice in milliseconds.

**VOICE1,2 SPLTEMPO** - Locks the splice time to the global tempo. For example, if the global tempo is 120 bpm and the tempo is set to a quarter note (1/4) then the time will be 500 ms (one echo per beat). To ignore the global tempo set the tempo control to **NONE**.

**VOICE1,2 FEEDBACK** - Sets the feedback of the voice to the input. By delaying and feeding a voice back strange pitch effects can be created as the note is translated pitch again and again.

**DIRECTION** - Sets the “direction” of the splice playback. Try setting to **REVERSE** for spacey effects.

**FEEDBACK TYPE** - Selects the type of feedback. **DUAL** sends the individual voices back to their respective delay lines. **BOTH** mixes the voices and sends them back to both delay lines. **PING-PONG** sends each voice to the opposite delay line.

**HICUT FREQ** - Sets the high-frequency rolloff of the pitched signal using a 12 dB / octave filter. This can be used to adjust the timbre of the voices.

## Stereo Enhancer

The Stereo Enhancer is used to increase the apparent stereo separation between the left and right outputs. When used judiciously it can make a stereo track appear “fuller” and “wider”.

**WIDTH** - Sets the phase difference between the left and right channels. Adjust until the desired effect is achieved. Certain frequencies may cancel each other at various settings, experiment with this to achieve the desired enhancement and frequency response.

**INVERT** - Allows inversion of the left or right channel if desired. Use in conjunction with the width control to adjust frequency and apparent widening.

**PAN** - Sometimes the effect will cause a shift in the apparent localization of the instrument. The pan control may be used to compensate for this.

## Effects Loop / Aux. Out

The Axe-Fx has a fully routable effects loop which allows you to use outboard processors anywhere in the signal chain. The effects loop can also be used as an auxiliary output for live stage monitoring through an amplifier and cabinet or as a general purpose output. To use the effects loop as an auxiliary output the output of the block is simply not connected. Alternatively you can place the effects loop directly in the signal chain but not connect anything to the **INPUT2 / EFF. RETURN** jack. The Axe-Fx senses if the effects return is not used and then just uses the loop as an output.


To use the effects loop as an on-stage monitor with a guitar amp (or head and cabinet) place the loop BEFORE any cabinet simulation blocks. For example, if you want to send a fully processed, stereo feed to the P.A. system and monitor your sound on-stage you would set up a chain like the following:

***AMP - CHORUS - DELAY - REVERB - EFFECTS LOOP - CABINET***

Note that the effects loop is before the cabinet. The main output would then be fully processed including the cabinet simulation. If you were to send this signal to an amp/cabinet combination it would probably be excessively muddy.

If your on-stage monitoring equipment is full-range then you can place the effects loop after the cabinet or simply use the un-balanced **OUTPUT 1** jacks for monitoring and connect the balanced jacks to the P.A.

## Mixer



The Mixer is a simple linear mixer that mixes the four rows feeding the block according to the gains for each row. The Mixer allows you to fine-tune levels, or cross-fade between effects. This is especially useful for cross-fading amps or delays.

Each gain control corresponds to a row in the routing matrix. To adjust, for example, the gain for the effect in row two preceding this block, simply adjust **GAIN2**.

The **PAN** controls allow you to select the balance of left and right from each row summed into the outputs. This is useful if you have differing signals in the left and right channels on a row. For example, you can use set up a routing where two amp blocks feed a single cabinet block with one amp panned hard left, the other panned hard right. You can now fade between the two amp blocks using the **PAN** control. Attach the **PAN** control to a modifier for real-time control.

The controls are linear (as opposed to logarithmic like most other gain controls). This makes setting up cross-fades much easier.

## Feedback Send / Return

The Feedback Send and Return blocks allow you to feedback sound from one point in the routing to any other point.

The Send block has no parameters, while the Return block has a basic mixer. Adjust the **MIX** control to set the ratio of direct and feedback signals.

Best results are achieved when feeding back a pure delayed signal. If any direct signal is fed back the resulting loop will usually be unstable and/or sound strange due to phase cancellation.

*Warning: Use caution with the Feedback blocks as you can easily program an unstable loop and cause internal clipping of the signal and/or very high sound levels which can damage your hearing. Always start with the **MIX** control on zero and slowly bring it up. If you start to hear squealing or other signs of instability return the **MIX** control to zero and analyze your routing for possible causes of instability.*

# Controllers and Modifiers

The Axe-Fx allows control over many of the various effect parameters. In essence a controller is like a robot that turns a knob for you. There are two basic types of controllers: internal and external. Internal controllers are automatic controllers that are generated by the Axe-Fx based on various parameters and conditions. External controllers are those generated by a MIDI device or a pedal for example. A modifier is a transform from the value generated by the controller to a value given to the parameter. Modifiers allow you to change the direction a parameter moves, smooth the response and select which controller is attached to the parameter. A modifier tells the robot how to move the knob.

## Controllers

The Axe-Fx controllers are internal and external sources that generate control information. This information can then be used to vary a parameter in real-time. Internal controllers automatically generate control information, external controllers generate control information based on input from the user, typically from the movement of an expression pedal. The control information is given to a modifier which in turn varies the desired parameter.

## Tempo

The most fundamental internal controller is the tempo controller. The tempo controller is special in that it cannot be directly connected to a parameter but many "rate" or "time" parameters can be set to depend on it. To use the tempo controller simply set the **TEMPO** parameter of the effect to the desired note duration. To set the Tempo either turn the knob or tap the desired tempo in using the **TEMPO** button. Tempo can also be tapped in using a pedal or MIDI CC message.

There are two tempo constructs in the Axe-Fx. The System Tempo is the tempo currently being used. The Global Tempo is the last entered tempo. Entering a new tempo automatically updates the System Tempo and sets the Global Tempo to equal the System Tempo. The current System Tempo is saved with a preset during a preset save operation.

Presets can either set the System Tempo to the tempo value stored in the preset, which is the tempo at the time the preset was saved, or the Global Tempo. This is done using the **TEMPO TO USE** parameter described below.

**TEMPO** - Sets the current System Tempo. Whenever a tempo is entered, whether via this control or by tapping or by MIDI clock, the System and Global Tempos are set to this value. The Global Tempo is not affected by the tempo stored with a preset when the preset is recalled and remains in effect.

**TEMPO TO USE** - Selects what tempo to use when recalling the preset. Selecting **PRESET** tells the Axe-Fx to set the System Tempo to the tempo stored with the preset. Selecting **GLOBAL** tells the unit to use the last entered tempo. If the value is **PRESET** the current tempo will change to the tempo stored with the preset, but the Global Tempo will remain at the last entered tempo. Recalling a preset with this value set to **GLOBAL** will load the Global Tempo into the System Tempo.

**AUTO DELAY** - When set to ON, any delay blocks that are bypassed will become active whenever a new tempo is input. This allows recalling a preset with a delay block bypassed and then automatically activating the delay when tapping in a new tempo.

## LFO's

The Axe-Fx contains two Low Frequency Oscillators (LFO's) that can generate various low-frequency waveforms for use in parameter modulation. The controls for each are identical.

**TYPE** - Sets the waveform type.

**RATE** - Sets the frequency of the LFO.

**DEPTH** - Sets the amplitude of the LFO.

**DUTY CYCLE** - For all waveforms except sine this allows you to vary the shape of the wave.

**OUTB PHASE** - Sets the phase of the secondary output (Output B). At maximum the secondary output is out of phase with the primary output (Output A).

**TEMPO** - Locks the LFO frequency to the current tempo. This overrides the RATE control.

## ADSR's

The Axe-Fx contains two Attack-Decay-Sustain-Release (ADSR) generators. These can be used to generate sequences that can then be used to control parameters. The graph shows the relative shape of the ADSR curve as its parameters are adjusted.

**MODE** - Selects the trigger mode of the ADSR:

- **ONCE**: The sequence plays when the threshold is exceeded.
- **LOOP**: The sequence repeats as long as the signal is above the threshold.
- **SUSTAIN**: The sequence stays at the sustain level until the signal drops below the threshold. The remainder of the sequence is then played.

**RETRIG** - When Retrig is on, sequences will reset to the beginning whenever the threshold is crossed from below to above.

**ATTACK** - The attack or rise-time of the sequence. This is the first line in the graph.

**DECAY** - The time to go from the peak level to the sustain level. The second line in the graph.

**SUSTAIN** - The time the sequence remains at the sustain level. The third, flat, line.

**LEVEL** - The sustain level in percent of full-scale.

**RELEASE** - The time to go from the sustain level to zero. The last line in the graph.

**THRSHLD** - The threshold level in dB. When the signal crosses this value the sequence is triggered.

## Sequencer

The Sequencer generates a sequence of values. When the last stage of the sequence is reached the sequence starts over. The Sequencer can be used to generate repetitive patterns in time with the beat of the song.

**RATE** - Sets the rate at which the sequence is stepped through. A rate of 1 Hz will cause the sequencer to step through the stages at a rate of one stage per second.

**TEMPO** - Locks the rate to the global tempo. Set to none for manual control of rate, set to the desired time signature to lock the rate to the current tempo.

**STAGES** - Sets the number of stages in the sequence. For example, if **STAGES** is 3, the sequencer will step through the stages as 1, 2, 3, 1, 2, 3, 1, etc.

**STAGEn** - Sets the value at that stage of the sequence.

*NOTE: The Sequencer features a random sequence generator. When in the Sequencer menu pressing **ENTER** will load a random set of values into the stages.*

## Envelope

The Envelope follower follows the envelope of the input signal. The harder you play the greater the value out of the Envelope follower. The Envelope follower makes possible dynamic parameter control such as ducking delay or touch-wah.

**THRESH** - The threshold level in dB. When the input signal is greater than this value the output of the follower will track the envelope of the input with a rate set by the attack time. If less than this value the output will decay at the release rate.

**ATTACK** - The rate at which the follower output follows signals increasing in power.

**RELEASE** - The rate at which the follower output follows signals decreasing in power.

**GAIN** - When using long attack times this can be used to compensate for the lower output level from the follower.



## Pitch

The Axe-Fx has a fast built-in Pitch detector. It is completely automatic and has no adjustable parameters. The value from the pitch detector is proportional to the frequency of the note played, higher notes give a higher value. If multiple notes are played at once the pitch detector will attempt to find the lowest pitch but may not be able to lock onto it. The pitch detector works best with single notes.


## External Controllers

The Axe-Fx supports up to eight external controllers. You can attach these to the PEDAL 1,2 jacks or to any MIDI Continuous Controller (see I/O setup).

## Modifiers

Modifiers act as a “middleman” between the control information from a controller and a parameter. The data from a controller is manipulated by a modifier and then used to vary an effect parameter. The Axe-Fx contains 16 modifiers. In its simplest form a modifier simply passes the data unaltered from a controller to a parameter. For example, an LFO can be used to directly control the panning of an effect output. Often times, though, you will want to manipulate the data from a controller. A modifier allows you to change the response of a parameter to a given controller.

The first step in using a modifier is attaching it to the desired effect parameter that you wish to control. To attach a parameter to a controller the parameter must be controllable. Controllable parameters are indicated by a symbol beneath the knob:



When the parameter is attached to a controller via a modifier the indicator has a line through it indicating that it is attached. For parameters in a list, the symbol above appears to the right of the parameter in the list.

To attach a controller to a parameter, select the parameter with the navigation buttons then press **ENTER**. This brings up the **MODIFIER** menu.

Once the menu is brought up the modifier must be attached to a source controller. This is the control information source that will be used to vary the parameter. You can choose any of the internal or external controllers as a source (or none to remove the modifier). Once the modifier is attached to a source you can vary the response curve and the damping to suit the desired response.

To remove a modifier select the parameter with the navigation buttons and press **ENTER**. Set the source to none then press exit. This will remove the modifier and restore the parameter's value to its stored value.

## Parameters

**SOURCE** - This is the controller that will be used to control the parameter. There are a variety of different sources available:

- **NONE** - Controller is detached.
- **LFO1A/B** - Selects the 'A' or 'B' output of LFO1 (see above).
- **LFO2A/B** - Selects the 'A' or 'B' output of LFO2 (see above).
- **ADSR1/2** - Selects ADSR1/2.
- **SEQNCR** - Selects the Sequencer.
- **ENVLPE** - Selects the Envelope follower.
- **PITCH** - Selects the Pitch detector.
- **EXTRNx** - Selects an External Controller. There are eight external controllers. These can be assigned to the pedal inputs or to MIDI continuous controllers (see I/O Setup).

**START** - Sets the start point for the transform.

**MID** - Sets the mid point for the transform.

**END** - Sets the end point for the transform.

**SLOPE** - Sets the shape of the curve.

**SCALE** - Sets the scale factor for the transform. The resulting curve is multiplied by this value.

**OFFSET** - Sets the offset. The curve is offset by this value

The **SCALE** and **OFFSET** parameters allow the user to position the modifier and control the excursion once an initial transfer function is set with the other parameters. For simple linear transfer functions, one need only use the **SCALE** and **OFFSET** parameters, leaving the others at their default values.

**DAMPING** - Sets how fast the output changes with the input. To slow the response rate increase the damping. This can be used to "de-click" a controller that changes rapidly.

This is especially useful when using controllers that have step-change responses such as an LFO with a square-wave or sawtooth waveform or the sequencer. In these examples the value of the controller jumps from one value to another instantly. If these values are then connected to a parameter, that parameter will jump from one value to another instantly as well. Many times this can cause an audible click or pop, especially if the parameter is a volume level or frequency parameter. By increasing the damping, the parameter will not jump to the new value but slide to the new value at a rate dictated by the damping value.

The damping control is also effective when using an expression pedal to control a parameter. It can help smooth out the pedals response, especially if the pedal's potentiometer has gotten "scratchy".

### **Detaching a Controller**

To detach a controller set the source to **NONE** and press **EXIT**.

# Global Parameters

The Axe-Fx Global Parameters menu is accessed by pressing the **GLOBAL** menu button. The Global Parameters allows you to set the overall tone and mix of the Axe-Fx. These settings are stored independently of the presets and restored at each power-on.

There are four pages: **CONFIG**, **OUT1**, **OUT2** and **MIX**.

The **OUT1** and **OUT2** pages allow fine tuning of the tone for each of the outputs. Here you can make adjustments to the basic tone of your Axe-Fx that affects all presets. This comes in handy when using the Axe-Fx in different environments where the acoustics may vary.

The **MIX** page allows overall control of the reverb and effects mix. As previously discussed the Global Mix allows you to vary the reverb and effects mix across all presets. This is useful when using the Axe-Fx in different environments where the ambience may vary. Note that the effects mix only affects those effects that have their **GLBL MIX** control set to **ON**.

The **CONFIG** page allows for global configuration of the amp and cabinet simulations as well as delay spillover control.

**POWER AMP** - Setting this to **BYPASSED** defeats the power amp simulation for all presets. This is useful when you are using the Axe-Fx with a tube amp.

**CABINET** - Turning the **CABINET** to **BYPASSED** bypasses the Cabinet blocks in all presets. Use this when you are using the Axe-Fx into an amplifier > guitar cabinet setup. This allows using presets with cabinets in them in varying situations. For direct recording or into a full-range sound reinforcement system (i.e. PA or home stereo) turn **CABINET** to **ACTIVE** (enable the Cabinet Emulators). If connecting to a guitar amp with integral speakers or a separate amplifier and guitar cabinet turn **CABINET** to **BYPASSED**. This defeats the Cabinet Emulators and presents the full-range signal to the amplifier/cabinet resulting in the proper tonal response. If this is not done the high frequencies will be excessively attenuated possibly resulting in a muffled or muddy sound.

**DELAY SPILL** - Setting this to **ON** disables the clearing of all delay lines during preset change. This in turn allows delays, reverbs and any other delay based effects to “spillover” to the new preset Setting this to **OFF** clears all delay lines and prevents any spillover.

# Tuner

Pressing the **TUNER** button brings up the Axe-Fx tuner display. There are three pages. The first page is the basic tuner display. The second page allows you to configure the tuner and the third page allows you to enter custom tuning offsets.

**CAL** - This sets the reference frequency for the tuner.

**MUTE** - When set to **ON** this mutes the sound out of the Axe-Fx when in the tuner menu.

**USE OFFSETS** - When set to **ON** the custom temperament offsets entered on the **OFFSETS** page are applied to the tuner display.

# Utilities

The Utilities menu consists of the *LCD*, *PRESET*, *STATUS*, *RESET* and *FIRMWARE* pages.

## LCD

On this page you can adjust the contrast of the LCD.

## Preset

### Preset Dump

These functions allow you to save presets to a MIDI librarian (or MIDI librarian software on a PC). Connect **MIDI OUT** to the MIDI librarian device. To save a preset simply recall the desired preset, select the function and press **ENTER**. The preset data is dumped in SysEx format.

To restore a preset from a MIDI librarian connect the device to **MIDI IN** and send the SysEx data into the Axe-Fx. The Axe-Fx automatically loads the data into its edit buffer. You can then save the downloaded data to the location of your choice.

To dump a bank of presets simply select the desired bank to dump and press **ENTER**. Bank A contains presets 0 through 127, Bank B contains 128 through 255 and Bank C contains presets 256 - 383. It may take several minutes to dump all the data in a bank. When saving the data to your librarian device (or PC) be sure to name the saved data to indicate the bank in which the data originated (i.e. BankA.syx). This will eliminate confusion if the need arises to restore a bank.

It is good practice to back up your presets regularly just as it's good practice to back up the data on your computer.

To restore a bank of presets connect the MIDI librarian to **MIDI IN** and send the SysEx data to the Axe-Fx. The Axe-Fx automatically recognizes the data as a Bank Dump and loads the data into its battery backed memory. **CAUTION: THIS WILL OVERWRITE ALL DATA IN THE BANK.**

Data from one Axe-Fx can be loaded into another Axe-Fx using this same method. Simply connect the **MIDI OUT** of the first Axe-Fx to the **MIDI IN** of the second. A bank from the first unit can then be loaded into the second unit.

### Preset Update

This function allows you to update all presets to the latest protocol. The Axe-Fx can read presets stored in either version 1.0 or 2.0 protocol. When a preset is saved it is saved in the latest protocol. If you've just updated the firmware to 2.0 or later you can convert all your presets to the latest protocol by using this function.

## Preset Backup

This function allows you to save the first 64 presets to the Axe-Fx's non-volatile FLASH memory. In the event that the internal battery fails or someone messes with your presets you can recall (see below) these presets back into main memory. By arranging your presets so that the ones you use for performance are in the first 64 locations you can save these to FLASH memory and be able to recall them in an emergency.

## Backup Recall

This function allows you to recall the first 64 presets from the Axe-Fx's non-volatile FLASH memory. The Axe-Fx automatically checks to see if the FLASH memory contains valid preset data and aborts the procedure if none is found.

*NOTE: When updating firmware the entire FLASH memory is erased and any presets backed up will be erased as well. After updating, perform the Preset Backup function to re-save the presets. It is good practice to back up your presets regularly both to the FLASH and also to an outboard storage device such as a PC so that if your unit is lost or stolen you can reload your custom presets into a new unit and avoid lengthy reprogramming.*

## Status

The **STATUS** page allows you to monitor the input levels and CPU usage of the Axe-Fx. If programming a VERY complicated preset you may run out of CPU power. The Axe-Fx has enough horsepower to run at least 10 effects simultaneously. If the CPU utilization is approaching 90% you may not be able to add a desired effect to the preset. Naturally some effects use much more power than others, the amplifiers using the most. The Axe-Fx does not allow the total CPU load to exceed 98% as the unit could then become unresponsive.

The Axe-Fx uses worst-case scenarios in determining whether enough power is left to place an effect and may not let you place an effect even if seemingly enough power is left. For example the chorus can use up to 8% of the CPU if set to 8 voices and with controllers attached to all its parameters. However it normally only uses a few percent. The Axe-Fx assumes the worst case and checks to see if CPU utilization is less than  $98 - 8 = 90\%$ . This is done to prevent overloading the CPU if the number of voices is increased.

Also, an effect is always running, even if bypassed so the CPU utilization does not change if an effect is bypassed. If you need more CPU resources check to see if you have any effects bypassed that you don't need and, if so, remove them. This will reduce the CPU usage accordingly.

## Reset

To reset all the factory parameter in your Axe-Fx select this page and press **ENTER**. This will reset the Global parameters, the MIDI configuration, Continuous Controller setup and Pedal configuration. This will not clear or otherwise alter any preset information.

## Firmware

This page allows you to update the firmware of your Axe-Fx. Follow the instructions that accompany the firmware.



# Tips and Tricks

## Achieving ultimate tone

Ultimate tone is the Holy Grail for guitar players and is a combination of many factors. To help you achieve the sound you are looking for follow these guidelines:

### **Choose the amplifier type carefully**

The amp types all have their own unique voicing and certain types are better suited to particular tones than others. Also experiment with the power amp parameters. The Depth, Sag and Master controls can make subtle changes to the tone of an amp that really bring out its character.

### **Experiment with the Drive**

A lower gain amp type can turn into a raging shred machine with a Drive block feeding it. Try putting a TS DISTORTION type in front of the Plexi amplifier type for example.

### **Experiment with the Cabinets and Microphones**

A different Cabinet type can change the sound of an amp dramatically. Start with L/R cabinets linked and audition the various cabs and mics. Then unlink the cabs/mics and experiment with different cab/mic combinations. You can fill out the sound by using different types left/right and adjusting the panning.

### **Use the EQ**

EQ can make a HUGE difference in sound. Try placing EQ before AND after the amplifier block. Subtle EQ adjustments can tighten up the sound or increase the depth. The Axe-Fx has a lot of EQ resources for just this reason. Take advantage of them.

## Using Your Axe-Fx with a Guitar Amp

Your Axe-Fx is equally suited for use with a full-range monitoring system or with a standard guitar amplifier. A few prefacing comments are in order:

From the factory the Axe-Fx is designed to interface to full-range recording or sound reproduction devices, i.e. studio monitors, sound cards, etc. The Axe-Fx fully simulates the entire audio chain of a typical guitar rig including the preamp, power amp, effects, speaker cabinet and microphone.

Often times, however, you may wish to connect your Axe-Fx to something other than a full-range device, i.e. a guitar amp. In this situation be aware that the guitar amp is already providing at least the speaker cabinet part of the signal chain. If you were to leave the Cabinet Simulation active in your Axe-Fx then the audio would basically be passing through a speaker cab in effect twice (once in the Axe-Fx, once in the external cab). This can have a detrimental effect on the sound quality and usually ends up being muddy as the high-frequencies are excessively attenuated and other frequencies may be unnaturally emphasized.

If you are connecting the Axe-Fx to a tube power amp as well, then once again the signal is effectively passed through a power amp twice (once in the Axe-Fx, once in the external tube amp).

For this reason the Axe-Fx allows you to defeat the power amp simulations and the cabinet simulations. The power amp simulation can be defeated by turning the **SAG** control in the Amp block to zero. The cabinet simulation can be defeated either globally via the Cabinet Bypass switch (in the **GLOBAL MIX** menu) or by bypassing or removing the cabinet block from the signal chain.

To use the Axe-Fx with a standard guitar amp the preferred method of connection would be to plug your guitar into the Axe-Fx and the output of the Axe-Fx into the loop return or power-amp in put (if so equipped) of your amp. This bypasses the preamp of your guitar amp and uses only the amp's power amp and speaker. The Axe-Fx then provides the preamp emulation and tone shaping.

If your amp does not have an effects loop then plug the output of the Axe-Fx into the instrument input of the amp and turn the amp's mid control to full and the bass and treble to zero. On most amps this will actually be a flat response. You can fine tune the tone after, if desired.

If your guitar amp is solid-state then you will probably want to use the full amp simulation abilities of the Axe-Fx including the power amp simulation. If you are using a tube amp then you already have a tube power amp and you may want to defeat the power amp simulation. To do this turn the **SAG** control in the Amp block to zero.

Since you are running into a guitar speaker (or speakers) turn the Cabinet Simulation off in your Axe-Fx either by disabling it globally via the **GLOBAL** menu or by bypassing or removing that block in a preset.

The Axe-Fx also works great driving a dedicated power amp and separate speaker cabinet. As above you should defeat the Cabinet Simulation (since you are already going to into a cabinet) and if using a tube power amp you may want to defeat the power amp simulation (using the **SAG** control).

## Using Your Axe-Fx Live

The Axe-Fx is designed with live performance in mind. For the ultimate in portability you could simply plug your guitar into the Axe-Fx and then plug your Axe-Fx into the P.A. mixing board. Send some signal to the mains and your monitor and you've got great sound with minimum hassle.

A more complicated approach would be to send the fully processed sound to the mixing board but tap off before the cabinet simulation and send that to a guitar amp or separate power amp and guitar cabinet. To do this you can use the auxiliary outputs of your Axe-Fx. Simply place the Effects Loop block as the second to last block in your signal chain and the Cabinet Simulator as the last block. The signal appearing at the **OUTPUT 2** jacks will be perfectly suitable for driving a guitar amp whereas the signal at the **OUTPUT 1** jacks will be perfect for sending to the P.A. system.

## Interference

Electric guitars are extremely effective at amplifying more than just the sound of the guitar but also the electromagnetic fields generated by TV sets, computer monitors, neon lights and illegal taxi radios. The best defense against these sources of interference is to have a well shielded guitar and to maximize the distance between the guitar and these sources. If you are working at a computer consider using an LCD monitor as these do not generate the high-intensity magnetic fields that CRT monitors do.

## Maintenance

Your Axe-Fx was built using the highest quality components available. No routine maintenance is required. To clean the unit use a mild detergent and water solution. Do not use any abrasives or harsh chemicals as these can damage the finish of the unit.

If your unit is malfunctioning do not attempt to service it yourself. The Axe-Fx is more like a computer than a tube amp and has no user serviceable components. **TO PREVENT RISK OF ELECTRICAL SHOCK DO NOT OPEN THE CHASSIS.** If you determine that your unit is malfunctioning please contact the factory to arrange for servicing.

*Note: The Axe-Fx contains a small internal cooling fan. This keeps the CPU within proper operating temperature under extreme ambient temperatures. You may notice a slight whirring noise if you put your ear close to the unit. This is normal.*

# Warranty Information

Fractal Audio Systems warrants that your new Fractal Audio Systems product, shall be free of defects in materials and workmanship for a period of one (1) year from the original date of purchase.

During the warranty period, Fractal Audio Systems shall, at its sole option, either repair or replace any product that proves to be defective upon inspection by Fractal Audio Systems.

Fractal Audio Systems reserves the right to update any unit returned for repair and to change or improve the design of the product at any time without notice. Fractal Audio Systems reserves the right to use reconditioned parts and assemblies as warranty replacements for authorized repairs. This warranty is extended to the original retail purchaser.

This is your sole warranty. Fractal Audio Systems does not authorize any third party, including any dealer or sales representative, to assume any liability on behalf of Fractal Audio Systems or to make any warranty for Fractal Audio Systems. Fractal Audio Systems may, at its option, require proof of original purchase date in the form of a dated copy of original authorized dealer's invoice or sales receipt. Service and repairs of Fractal Audio Systems products are to be performed only at the Fractal Audio Systems factory or a Fractal Audio Systems authorized service center. Fractal Audio Systems may require advanced authorization of repairs to authorized service centers. Unauthorized service, repair or modification will void this warranty.

## DISCLAIMER AND LIMITATION OF WARRANTY

THE FOREGOING WARRANTY IS THE ONLY WARRANTY GIVEN BY FRACTAL AUDIO SYSTEMS AND IS IN LIEU OF ALL OTHER WARRANTIES. ALL IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR ANY PARTICULAR PURPOSE, EXCEEDING THE SPECIFIC PROVISIONS OF THIS WARRANTY ARE HEREBY DISCLAIMED AND EXCLUDED FROM THIS WARRANTY. UPON EXPIRATION OF THE APPLICABLE EXPRESS WARRANTY PERIOD (1 YEAR), FRACTAL AUDIO SYSTEMS SHALL HAVE NO FURTHER WARRANTY OBLIGATION OF ANY KIND, EXPRESS OR IMPLIED. FRACTAL AUDIO SYSTEMS SHALL IN NO EVENT BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES SUFFERED BY THE PURCHASER OR ANY THIRD PARTY, INCLUDING WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS OR BUSINESS, OR DAMAGES RESULTING FROM USE OR PERFORMANCE OF THE PRODUCT, WHETHER IN CONTRACT OR IN TORT. FRACTAL AUDIO SYSTEMS SHALL NOT BE LIABLE FOR ANY EXPENSES, CLAIMS, OR SUITS ARISING OUT OF OR RELATING TO ANY OF THE FOREGOING. Some states do not allow the exclusion or limitation of implied warranties so some of the above limitations and exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary, from state to state. This warranty only applies to products sold and used in the USA and Canada. Fractal Audio Systems shall not be liable for damages or loss resulting from the negligent or intentional acts of the shipper or its contracted affiliates. You should contact the shipper for proper claims procedures in the event of damage or loss resulting from shipment.

# Specifications

## Front Panel Input

Connector:	1/4" phone jack, unbalanced.
Impedance:	1 Mohm
Max. Input Level:	+12 dBu (conditioned for guitar use)

## Rear Inputs

Connector:	1/4" phone jack, unbalanced.
Impedance:	1 Mohm
Max. Input Level:	+18 dBu

## A/D Conversion

Bit Depth:	24 bits
Sample Rate:	48 kHz
Dynamic Range:	> 105 dB
Frequency Response:	20 - 20kHz, +0 / -3 dB
Crosstalk:	<-60 dB over full bandwidth

## Analog Outputs

Connectors:	1/4" phone jack unbalanced, XLR balanced (for main output)
Impedance:	100 ohm
Max Output Level:	+18 dBu
Dynamic Range:	> 105 dB
Frequency Response:	20 - 20kHz, +0 / -3 dB
Crosstalk:	<-60 dB over full bandwidth

## Digital I/O

Connectors:	RCA Coaxial Type for S/PDIF I/O, XLR for AES Out
Format:	S/PDIF - 24 bit
Sample Rate	48 kHz

## MIDI Interface

Input Connector:	7-pin DIN (pins 6&7 connected to phantom power in jack)
Out/Thru Connectors:	5-pin DIN

## Pedal Interface

Connectors:	1/4" TRS phone jacks
Format:	Compatible with expression and momentary or latching pedals

## General

Finish:	Powdercoated steel chassis with anodized aluminum faceplate
LCD:	128x64 dot matrix graphic display
Dimensions:	19" x 3.5" x 12" (483 x 88 x 305 mm)
Weight:	8 lbs (3.6 kg)
Input Voltage:	100 to 240 VAC, 47 - 63 Hz (universal input)
Power Consumption:	< 10 W
Backup Battery Life:	> 10 years

## Environmental

Operating Temperature:	32 to 122 °F (0 to 50 °C)
Storage Temperature:	-22 to 167 °F (-30 to 70 °C)
Humidity:	Max. 90% non-condensing